

Introduction

The information contained in this Troubleshooting Guide has been compiled from various sources within the marine industry. Any reference to a specific product or brand is not intended for commercial purposes. References to test equipment and products are based upon the information available to the staff of CDI Electronics. **This information is designed for use as a reference guide by a professional marine technician.** CDI Electronics cannot be held liable for the misuse or abuse of the information contained herein. The staff tries to make the information as accurate as possible. However, CDI Electronics cannot assume responsibility for either the data accuracy or the consequences of the data's application.

© CDI Electronics 2004

Safety Issues

Always remember to treat the outboard engine with respect. The engine uses high voltage for ignition and contains several moving components. Always be aware of moving mechanical parts, the surrounding area, and the position of your hands and body near the engine.

- **Never touch electrical components with wet hands.**
- **Whenever the power source is not needed, disconnect the cable from the negative terminal.**
- **Never reverse the battery leads when you connect the battery or disconnect the terminals while the engine is running.**
- **Never touch high-tension leads (spark plug leads) with any ungrounded tools while the engine is running.**
- **Never install equipment with requirements exceeding the generating power of the engine. Reference the service manual for values.**
- **Attempt to protect the electronic components from water.**
- **Insure fuel lines, harnesses, and oil lines are properly routed. Failure to follow this rule could result in a fire hazard.**
- **Make sure all ground leads are clean and tight.**

Recommended Marine Shop Electrical Test Equipment and Tools

The following is a listing of tools available from CDI Electronics and recommended for testing late model engines:

Part Number	Description	Remarks/Use
511-9764	Neon Spark Tester	Sealed single cylinder has removable ground clamp can be used for running tests
511-9766	Sealed Spark Gap Tester	Allows for testing up to 8 cylinder for cranking tests. Sealed design reduces the chance of engine fire.
511-9770	Piercing Probes	Allows access to wires for testing without removing the connection. Tiny hole usually reseals itself.
511-9773	DVA (Peak Voltage)Adapter	Unit automatically compensates for polarity. Can be used with most quality Multimeters
511-9775	Load Resistor	Used to load the output of ignition modules when testing ignition coils.
518-33A	CDI 33 Meter	Meter has voltage, amperage, diode check and ohms
	Includes 511-9773 DVA Adapter	DVA Adapter allows meter to read peak voltage
518-80TK	Fluke Temperature Adapter	Works with most digital Multimeters capable of reading millivolts.
520-ST80	DC Inductive Timing Light	DC Powered timing light with a very bright strobe light.
551-33GF	Gearcase Filler w/Check Valve	Universal design makes filling lower units easier. Check valve assembly helps prevent oil spills and makes filling easier.
551-34PV	Pressure/Vacuum Tester	Repairable metal combination unit does both vacuum and pressure testing.
551-5110	Flywheel Holder	Longer handle helps during use.
551-9765	Spark Plug Wire Puller	Grounded design reduces the chances of shocking.
553-2700	Amphenol Pin Tool Set	Set contains 1 each of 553-2697 (Insertion), 553-2698 (Pin Removal) and 553-2699 (Socket Removal)
553-9702	Sensor Gap Gauge Tool	Used to set the timer-base air gap on 1973-1978 OMC 3 and 4 cylinder engines with screw terminal power packs.
554-9706	Amp Pin Removal Tool	Used to remove the connector pins in the ignition system on Chrysler/Force engines using the Prestolite type ignitions. Also used on the Mercury TPI sensor connectors.
911-9783	Bullet Connector Kit	Contains 10 pieces each of the male, female and sleeves.
912-9708	Marine Terminal Kit	Contains 100+ pieces of hard to find terminals and heat shrink.
991-9705	Dielectric Grease	Use to keep water and corrosion out of connectors.
511-6996	Remote Starter For OMC	Used to replace the boat-side harness for engine testing, Fits most OMC engines 1969 to 2000.
511-7900	Remote Starter for Mercury	Used to replace the boat-side harness for engine testing, Fits most Mercury engines 1979 to 2000.
519-LB85	Load Bank	Used to load the battery when testing the battery charging output.

Optional Equipment

511-4017	OMC Optical Sensor Tester	Unique handheld tester that will efficiently test the optical ignition sensor.
511-0401	CDI 2 Cylinder Ignition Tester	New hand-held ignition tester generates high-voltage stator and low voltage trigger signals to test a variety of 2 cylinder ignition systems. Engine specific adapters are required. Includes 511-0402, 511-0403 and 511-0404 adapters.
520-ST84	Ferret Ultra Bright Timing Light	Ultra bright timing light is visible in bright sunlight. Also has a built-in tachometer for 2 and 4 stroke engines. This feature is a valuable diagnostic tool when troubleshooting ignition system problems.

Tricks to Testing with Minimal Test Equipment

All Engines

Please keep detailed records when you repair an engine. If an engine comes in with one cylinder not firing, mark which one on the work order/history.

Intermittent Firing: This problem can be very hard to isolate. A good inductive tachometer can be used to compare the RPM on all cylinders up through WOT (wide-open throttle). A significant difference in the RPM readings can help pinpoint a problem quickly.

Visually Check the Stator, Trigger, Rectifier/Regulator and Flywheel: Cracks, burned areas and bubbles in or on the components indicate a problem. If the battery charge windings on the stator are dark brown, black or burned on most or all of the posts, the rectifier/regulator is likely shorted as well. Any sign of rubbing on the outside of the stator indicates a problem in the upper or lower main bearings. A cracked trigger or outer charging magnets can cause many problems ranging from misfiring to no fire at all. Loose flywheel magnets can be dangerous, check the tightness of the bonding adhesive.

Rectifier/Regulators can cause problems ranging from a high-speed miss to a total shutdown. An easy check is to disconnect the stator leads to the rectifier (Make sure to insulate them) and retest. If the problem is gone – replace the rectifier/regulator.

Johnson/Evinrude

Open Timer Bases: When all cylinders fire with the spark plugs out, but will not with them installed, try re-gapping the sensors using P/N: 553-9702 Gap Gauge. (See the section on OMC ADI Ignitions page 22-24).

Engines with S.L.O.W. Features: If the customer is complaining that the engine won't rev up and shakes real bad, the S.L.O.W. function could be activating. If the engine is NOT overheating, a temperature sensor or VRO sensor failing early can cause this problem. Disconnect the TAN wires *at the power pack* and retest. If the engine performs normally, reconnect the tan wires one at a time until the problem recurs, then replace the last sensor you connected. Make sure that all of the TAN wires are located as far as possible from the spark plug wires. Also check the blocking diode in the engine harness.

Mercury 6 Cylinder Engines with ADI Ignitions

If more than one cylinder is not firing: Replace BOTH switch boxes unless you can pin the problem down to the trigger. Replacing just one switch box can result in damage to the engine if the remaining switch box on the engine has a problem in the bias circuit.

Always check the bias circuit: Disconnect the White/Black jumper between the switch boxes and check the resistance from the White/Black terminal on each switch box to engine ground. You should read 12-15,000 ohms on stock switch boxes, and 9,000-9,800 ohms on racing switch boxes. MAKE SURE THE READING IS THE SAME ON BOTH SWITCH BOXES! Any problem with the bias circuit and BOTH switch boxes must be replaced as a set.

No Fire on 1, 3, 5 or 2, 4, 6: Swap the stator leads from one switch box to the other. If the problem moves, replace the stator. If the problem remains on the same cylinders, replace the switch box. If the stator is replaced and the problem is still present, try another flywheel.

No Fire on One Cylinder: This can be caused by a defective blocking diode in the other switch box. Disconnect the White/Black jumper between the switch boxes and retest. If all cylinders are now firing, replace the switch box that was originally firing all three cylinders. To verify this condition, swap the trigger leads on the switch box that was originally firing all three cylinders. If the misfire moves to another cylinder, the switch box is bad.

Voltage Drop Measurement

Start by using a good digital auto-ranging voltmeter capable of reading 1/10th of a volt. The use of an auto-ranging meter will allow for more accurate testing without damaging the meter due to an incorrect range setting.

Remove the spark plug wires from the spark plugs and connect them to a spark gap tester and remove the emergency stop clip as well. This prevents the engine from starting and also reduces the chance of getting shocked by the ignition system.

The use of an ohmmeter to test a conductor or switch contact for their condition is not the best tool to use. In most cases, it is preferable to use a volt drop test to make sure the conductor, as well as the connection, is in good condition.

Before testing, remove and clean all battery cables and connection points.

Testing the Positive Battery Cable to the Engine

1. Select the DC Volts position on the meter.
2. Connect the Red (Positive) lead on the meter to the positive battery *POST*.
3. Connect the Black (Negative) lead on the meter to the starter solenoid terminal where the positive battery cable is connected.
4. Using a remote start switch, activate the starter solenoid to spin the engine and observe the reading on the meter. A reading above 0.6V indicates a bad cable or bad connection.
 - (a) If the meter reads above 0.6V, move the Black lead on the meter to the positive battery cable terminal on the starter solenoid and retest. If the reading drops to below 0.6V, the cable connection is bad.
 - (b) If the meter still reads above 0.6V, move the Black lead on the meter to the positive battery cable terminal on the battery and retest. If the reading drops to below 0.6V, the cable is bad or undersized.

Service Note: A bad power connection to the ignition or battery charging system can be found by connecting the Black lead on the meter to the power connection of the ignition system or charging system; then working your way back to the battery positive post. At no time should you see a reading above 1V.

Testing the Negative Battery Cable to the Engine

1. Select the DC Volts position on the meter.
2. Connect the Black (Negative) lead on the meter to the negative battery *POST*.
3. Connect the Red (Positive) lead on the meter to the engine block where the negative battery cable is connected.
4. Using a remote start switch, activate the starter solenoid to spin the engine and observe the reading on the meter. A reading above 0.6V is an indicator of a bad cable or bad connection.
 - (a) If the meter reads above 0.6V, move the Red lead on the meter to the negative battery cable terminal on the engine block and retest. If the reading drops to below 0.6V, the cable connection is bad.
 - (b) If the meter still reads above 0.6V, move the Red lead on the meter to the negative battery cable terminal on the battery and retest. If the reading drops to below 0.6V, the cable is bad or undersized.

A bad ground connection to the ignition and battery charging system can be found by connecting the Red lead on the meter to the ground connection of the ignition or battery charging system; then working your way back to the battery negative post. At no time should you see a reading above 1V.

Johnson/Evinrude Model to Year Identification for 1980 and newer Engines

“INTRODUCES”

I	N	T	R	O	D	U	C	E	S
1	2	3	4	5	6	7	8	9	0

Example: J150TTLCE would be a 1989 150 HP Johnson and aE175STEU would be a 1997 175 HP Evinrude.

Engine Wiring Cross Reference Chart for Most Outboards

Circuit	Mercury PRE- 1978	Mercury 1978 & UP	OMC	Yamaha	Force PRE- 1994	Force 1994 & UP	Suzuki
Power	Red	Red	Red	Red	Red	Red/Purple	White
Ign Switch	White	Purple	Purple	Yellow	Blue	Red/Blue	Gray
Eng Gnd	Black	Black	Black	Black	Black	Black	Black
Kill Circuit	Orange Salmon White	Blk/Yellow	Blk/Yellow	White	White	Blk/Yellow	Green Red Blue
Eng Start	Yellow	Yellow/Red	Yellow/Red	Brown	Yellow	Yellow/Red	Brown Yellow/Red
Tach	Brown	Gray	Gray	Green	Purple	Gray	Yellow
Battery Charge	Yellow/Red	Yellow Yellow/Blk	Yellow Yellow/Gry	Green	Yellow	Yellow Yellow/Blk	Yellow/Red
Stator CDI Power	Red White Blue(a)	Blue Blue/White Red Red/White Green/Wht Wht/Green	Brown Brown/Yel Brown/Blk Brown/Wht	Blue Brown Red Blk/Red	Blue Yellow Brown/Blue Brown/Yel	Blue Blue/White Red Red/White Green/Wht Wht/Green	Green Black/Red
Choke	Gray Blue	Yellow/Blk	Purple/Wht	Blue	Green	Yellow/Blk	Orange
Overheat Eng Temp	Tan	Tan	Tan (b) White/Blk(c)	Pink	Orange	Tan	Green/Yel

(a) Ignition Driver systems only, all others were battery driven systems.

(b) The stripe color on the Tan wire indicates the temperature at which the sensor trips.

(c) The White/Black wire is the cold engine temp indicator and shorts to Gnd at approx 105 deg F.

Blk = Black

Wht = White

Gry = Gray

Yel = Yellow

Blk = Black

ABYC Recommended Boat Wiring Color Codes


Color	Function	Comments
Yellow/Red Stripe (YR)	Engine Start Circuit	
Brown/Yellow Stripe (BY)	Bilge Blower	Alternate color is Yellow (Y)
Yellow Stripe (Y)	Bilge Blower	If used for DC negative, blower MUST be Brown/Yellow Stripe.
Dark Gray (Gy)	Navigation Lights	Fuse or Switch to lights
Dark Gray (Gy)	Tachometer	
Brown (Br)	Generator/Alternator	Charge Indicator Lights, Fuse or switch to pumps.
Orange (O)	Accessory Power	Ammeter to alternator output and accessory fuse or switches. Distribution Panel accessory switch.
Purple (Pu)	Ignition Instrument power	Ignition switch to coil and electrical instruments , Distribution Panel to electric instruments.
Dark Blue	Cabin and instrument lights	Fuse or switch to lights.
Light Blue (Lt Bl)	Oil Pressure	Oil sender to gauge.
Tan	Water Pressure	Temperature sender to gauge.
Pink (Pk)	Fuel Gauge	Fuel sender to gauge.
Green/White Stripe	Tilt/Trim down or in	Tilt and Trim circuits
Blue/White Stripe	Tilt/Trim up or out	Tilt and Trim circuits

Mercury

Battery CD Ignitions with Points

1. SERVICE NOTE: Check the battery voltage at approximately 3500-RPM, MAXIMUM reading allowable is 16 volts. Over 16 volts will damage the ignition. Check for loose connections or a bad battery. **Maintenance free batteries are NOT recommended for this application.** A CD Tester (CDI Electronics P/N: 511-9701) can be used to test the CD module, distributor cap, rotor button and spark plug wires on the engine.

Engine Wiring Connection for Testing Ignition Module



2. Clean all battery connections and engine grounds.
3. Disconnect the mercury tilt switch and retest. If the ignition works properly, replace the mercury switch.
4. Connect a spark gap tester to the spark plug wires and check for fire on *all cylinders*. If some cylinders fire and not others, the problem is likely in the distributor cap, rotor button or spark plug wires.
5. Connect a spark gap tester to the high-tension lead coming from the ignition coil and set it to approximately 7/16". When you crank the engine over, if it fires while the spark gap tester is connected to the coil and does not fire through the spark plug wires – there is a problem in the distributor cap, rotor button or spark plug wires.
6. Check voltage present on the white and red terminals while at cranking. It MUST be at least 9½ volts. If not, there is a problem in the harness, key switch, starter battery cables or battery.
7. Check DVA voltage on the green wire going to the coil, it should be over 100 volts at cranking.
8. Disconnect the brown points wires. Turn the ignition switch on and strike one of the brown points wire against engine ground. The unit should fire each time. If the coil does fire, this means the CD module is usually good and the points, points plate and grounding wire for the points plate should be checked.
9. Connect a spark gap tester to the high-tension leads coming from the distributor cap and set the gap to approximately 7/16". Align the rotor with #1 spark plug wire. Turn the ignition switch on and strike the brown points wire against engine ground (Or use a CD Tester). Only the #1 spark plug wire should fire. If any other spark plug wire now has fire, there is a problem in the distributor cap. Repeat the test for the other cylinders.
10. Perform a voltage drop test after the engine is repaired to see if there is a problem with the voltage going to the CD module. At cranking and while the engine is running, use a DC voltmeter and put the black meter lead on the battery POS (+) *post* and the red meter lead on the positive battery cable at the starter solenoid. Keep the black lead on the battery post and shift the red meter lead to the positive post of the rectifier, then to the red and white terminals on the switch box. If you find a reading above 0.6V, there is a problem at the point where the voltage jumped up. For example, if the meter reads 0.4V until you get to the white terminal and then jumps to 2.3V on the white terminal –this indicates a problem in the key switch, or harness. Repeat the test for the negative battery post by putting the black meter lead on the battery NEG (-) *post* and the red meter lead on the negative battery cable terminal, then shifting to the engine block, rectifier base and case ground of the CD module.

Mercury


Battery CD Ignitions without Points

Three Cylinder Engines with 332-4796/393-4797 Battery Type Ignitions

Note: A CD Tester by CDI Electronics (511-9701) or Merc-o-Tronics can be used to test the CD module, distributor cap, rotor button and spark plug wires on the engine while the Trigger Tester by CDI can be used to test the distributor trigger.

SERVICE NOTE: Check the battery voltage at approximately 3500 RPM, MAXIMUM reading allowable is 16 volts and minimum is 12V. Running below 12V or over 16 volts will damage the ignition. Check for loose connections or a bad battery. *Maintenance free batteries are NOT recommended for this application.*

Engine Wiring Connection for Testing Ignition Module



General:

1. Clean all battery connections and engine grounds.
2. Disconnect the mercury tilt switch and retest. If the ignition works properly, replace the mercury switch.
3. Connect a spark gap tester to the spark plug wires and check for fire on *all cylinders*. If some cylinders fire and not others, the problem is likely in the distributor cap, rotor button or spark plug wires.
4. Perform a voltage drop test after the engine is repaired to see if there is a problem with the voltage going to the CD module. At cranking and while the engine is running, use a DC voltmeter and put the black meter lead on the battery POS (+) *post* and the red meter lead on the positive battery cable at the starter solenoid. Keep the black lead on the battery post and shift the red meter lead to the positive post of the rectifier, then to the red and white terminals on the switch box. If you find a reading above 0.6V, there is a problem at the point where the voltage jumped up. For example, if the meter reads 0.4V until you get to the white terminal and then jumps to 2.3V on the white terminal –this indicates a problem in the key switch, or harness. Repeat the test for the negative battery post by putting the black meter lead on the battery NEG (-) *post* and the red meter lead on the negative battery cable terminal, then shifting to the engine block, rectifier base and case ground of the CD module.

NO SPARK ON ANY CYLINDER:

1. Connect a spark gap tester to the high-tension lead coming from the ignition coil and set it to approximately 7/16". When you crank the engine over, if it fires while the spark gap tester is connected to the coil and does not fire through the spark plug wires – there is a problem in the distributor cap, rotor button or spark plug wires.
2. Check the DC voltage present on the white and red terminals while at cranking. It MUST be at least 9½ volts. If not, there is a problem in the harness, key switch, starter battery cables or battery.
3. Check the DC voltage on the white/black trigger terminal while cranking, there must be at least 9V available with the trigger wire connected.
4. Check DVA voltage between the blue and black trigger wires (they must be connected to the switch box). You should read at least 3V. A low reading indicates a bad trigger.
5. Check DVA voltage on the green wire going to the coil, it should be over 100 volts at cranking.

ONLY HAS SPARK AS LONG AS THE STARTER IS ENGAGED:

This symptom usually indicates a bad trigger or low voltage.

NO SPARK OR INTERMITTENT ON ONE CYLINDER:

1. Connect a spark gap tester to the high-tension leads coming from the distributor cap and set the gap to approximately 7/16". Use of a CD Tester is highly recommended.
2. Align the rotor with #1 spark plug wire. Disconnect the trigger wires and connect a jumper wire from the white/black trigger terminal to the black trigger terminal on the switch box.
3. Connect another jumper wire to the blue trigger terminal turn the ignition switch on. Strike the jumper wire from the blue terminal against engine ground – (DO NOT HOLD THE JUMPER AGAINST ENGINE GROUND). Only the #1 spark plug wire should fire. If any other spark plug wire now has fire, there is a problem in the distributor cap.
4. Repeat the test for the other cylinders.

HIGH SPEED MISS:


Check the battery voltage on the red and white terminals of the switch box at high speed, the voltage should be between 12.5V and 16V DC. A reading outside this range will damage the CD module. If the readings are abnormal, perform the voltage drop test described above.

Four and Six Cylinder Engines with 332-2986/393-3736 Battery Type Ignitions

Note: A CD Tester like the one by CDI Electronics or Merc-o-Tronics can be used to test the CD module, distributor cap, rotor button and spark plug wires on the engine while the Trigger Tester by CDI can be used to test the distributor trigger.

SERVICE NOTE: Check the battery voltage at approximately 3500 RPM, MAXIMUM reading allowable is 16 volts and minimum is 12V. Running below 12V or over 16 volts will damage the ignition. Check for loose connections or a bad battery. *Maintenance free batteries are NOT recommended for this application.*

Engine Wiring Connection for Testing Ignition Module



General:

1. Clean all battery connections and engine grounds.
2. Disconnect the mercury tilt switch and retest. If the ignition works properly, replace the mercury switch.
3. Connect a spark gap tester to the spark plug wires and check for fire on *all cylinders*. If some cylinders fire and not others, the problem is likely in the distributor cap, rotor button or spark plug wires.
4. Perform a voltage drop test after the engine is repaired to see if there is a problem with the voltage going to the CD module. At cranking and while the engine is running, use a DC voltmeter and put the black meter lead on the battery POS (+) *post* and the red meter lead on the positive battery cable at the starter solenoid. Keep the black lead on the battery post and shift the red meter lead to the positive post of the rectifier, then to the red and white terminals on the switch box. If you find a reading above 0.6V, there is a problem at the point where the voltage jumped up. For example, if the meter reads 0.4V until you get to the white terminal and then jumps to 2.3V on the white terminal –this indicates a problem in the key switch, or harness. Repeat the test for the negative battery post by putting the black meter lead on the battery NEG (-) *post* and the red meter lead on the negative battery cable terminal, then shifting to the engine block, rectifier base and case ground of the CD module.

NO SPARK ON ANY CYLINDER:

1. Connect a spark gap tester to the high-tension lead coming from the ignition coil and set it to approximately 7/16". When you crank the engine over, if it fires while the spark gap tester is connected to the coil and does not fire through the spark plug wires – there is a problem in the distributor cap, rotor button or spark plug wires.
2. Check the DC voltage present on the white and red terminals while at cranking. It MUST be at least 9½ volts. If not, there is a problem in the harness, key switch, starter battery cables or battery.
3. Check the DC voltage on the brown trigger terminal while cranking, there must be at least 9V available with the trigger wire connected.
4. Check DVA voltage between the white and black trigger wires (they must be connected to the switch box). You should read at least 3V. A low reading indicates a bad trigger.
5. Check DVA voltage on the green wire going to the coil, it should be over 100 volts at cranking.

ONLY HAS SPARK AS LONG AS THE STARTER IS ENGAGED:

This symptom usually indicates a bad trigger or low voltage.

NO SPARK OR INTERMITTENT SPARK ON ONE CYLINDER:

1. Connect a spark gap tester to the high-tension leads coming from the distributor cap and set the gap to approximately 7/16". (Use of a CD Tester is recommended).
2. Align the rotor with #1 spark plug wire. Disconnect the trigger wires and connect a jumper wire from the brown trigger terminal to the white trigger terminal.
3. Connect another jumper wire to the black trigger terminal turn the ignition switch on. Strike the jumper wire from the black terminal against engine ground – (DO NO HOLD THE JUMPER AGAINST ENGINE GROUND). Only the #1 spark plug wire should fire. If any other spark plug wire has fire, there is a problem in the distributor cap.
4. Repeat the test for the other cylinders.

HIGH SPEED MISS:

1. Check the battery voltage on the red and white terminals of the switch box at high speed, the voltage should be between 12.5V and 16V DC. A reading outside this range will damage the CD module. If the readings are abnormal, perform the voltage drop test described above.
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a high miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.


Four Cylinder Engines 1970-1971 Engines with 337-4406/337-4411 Ignitions

WARNING: Check the battery voltage at approximately 3500 RPM, MAXIMUM allowable reading is 16 volts and minimum is 12V. Running below 12V or over 16 volts will damage the ignition. Check for loose connections or a bad battery. Maintenance free batteries are NOT recommended for this application.

SERVICE NOTE: Due to problems associated with this system, it is recommended that the system be converted over to a 332-2986/393-3736 type system. (CDI Electronics offers a conversion kit, P/N – 114-2986K1)

Engine Wiring Connection for Testing Ignition 337-4411 Module

4 Cylinder Battery Ignition



General:

1. Clean all battery connections and engine grounds.
2. Disconnect the mercury tilt switch and retest. If the ignition works properly, replace the mercury switch.
3. Connect a spark gap tester to the spark plug wires and check for fire on *all cylinders*. If some cylinders fire and not others, the problem is likely in the distributor cap, rotor button or spark plug wires.
4. Perform a voltage drop test after the engine is repaired to see if there is a problem with the voltage going to the CD module. At cranking and while the engine is running, use a DC voltmeter and put the black meter lead on the battery POS (+) *post* and the red meter lead on the positive battery cable at the starter solenoid. Keep the black lead on the battery post and shift the red meter lead to the positive post of the rectifier, then to the red and white terminals on the switch box. If you find a reading above 0.6V, there is a problem at the point where the voltage jumped up. For instance, if the meter reads 0.4V until you get to the white terminal and then jumps to 2.3V on the white terminal –this indicates a problem in the key switch, or harness. Repeat the test for the negative battery post by putting the black meter lead on the battery NEG (-) *post* and the red meter lead on the negative battery cable terminal, then shifting to the engine block, rectifier base and case ground of the CD module.

NO SPARK ON ANY CYLINDER:

1. If a mercury switch is connected to the switch box, disconnect it and retest. If you now have spark, replace the mercury switch.
2. Connect a spark gap tester to the high-tension lead coming from the ignition coil and set it to approximately 7/16". When you crank the engine over, if it fires while the spark gap tester is connected to the coil and does not fire through the spark plug wires – there is a problem in the distributor cap, rotor button or spark plug wires.
3. Check the DC voltage present on the white trigger wire and the red terminal of the switch box while cranking. It MUST be at least 9½ volts. If not, there is a problem in the harness, key switch, starter, battery cables or battery.
4. Check DVA voltage between the blue terminal and engine ground while cranking (The trigger wire must be connected to the switch box). You should read at least 9V.
5. Disconnect the wire from the blue terminal of the switch box and connect a jumper wire to the terminal. Strike the other end of the jumper wire against engine ground. The CD module should fire each time. Failure to fire usually indicates a bad CD module.
6. Check DVA voltage on the green wire going to the coil, it should be over 100 volts at cranking.

NO SPARK OR INTERMITTENT SPARK ON ONE CYLINDER:


1. Connect a spark gap tester to the spark plug wires coming from the distributor cap and set the air gap to approximately 7/16".
2. Align the rotor with #1 spark plug wire. Disconnect the wire from the blue terminal of the switch box and connect a jumper wire to the terminal. Strike the other end of the jumper wire against engine ground. Only the #1 spark plug wire should fire. If any other spark plug wire has fire, there is a problem in the distributor cap.
3. Repeat the test for the other cylinders.

NOTICE: The 4 cylinder engines using the 332-3213 ignition module and belt driven ignition driver DO NOT USE BATTERY VOLTAGE. Connecting 12V to the Red terminal will destroy the module.

Mercury Trigger Magnets
THE FLYWHEELS WITH THESE MAGNET DESIGNS CANNOT BE INTERCHANGED!!!!


Mercury CDM Hub Magnet Design

1996 to 2006 2, 3 and 4 cylinder engines with CDM Modules



Mercury Hub Magnet Design

Push-Pull Trigger Coil Design (1978-1996 on 2, 3 and 4 Cyl engines All 1978-2005 L6, 2.0L, 2.4L and 2.5L engines)



Note that the design of the magnet for the push-pull is the same for the 3, 4 and 6 cylinder engines using standard ADI ignitions. The trigger magnet for the CDM modules is completely different.

Mercury

Alternator Driven Ignitions

Two Cylinder Engines 1971-1975 (With Phase-Maker Ignition)

NO SPARK ON ONE OR BOTH CYLINDERS:

1. Disconnect the orange stop and retest. If the engine now has spark, the stop circuit has a fault.
2. Check the Stator resistance and DVA output as given below:

Wire Color	Check to Wire Color	Resistance	DVA Reading
Red wire	Yellow wire	320-550	Not Available
Blue wire	Yellow wire	3600-5500	Not Available
Green wire	Engine Ground	--	180V or more Connected

2. Disconnect the points wires (Brown and White) one at a time and retest. If the spark comes back on the one still connected when you disconnect one of them, the points or points wire is defective for the disconnected cylinder.
3. Disconnect the Green wires one at a time and retest. If the spark comes back on one cylinder, the ignition coil not connected is defective. Remember that the coils must not be the Black or Blue coils (these coils are not isolated ground).
4. Test the 336-4516 module as follows:

336-4516

REPAIR & RETURN

TEST UNIT WITH METER - OHM SCALE

1). CHECK STATOR COILS

A). BLUE / YELLOW 170 - 180Ω

B). RED / YELLOW 4.6- 4.7KΩ

CHECK WITH METER 4516 MODULE
USE THE FUNTION DIODE SCALE TO MEASURE UNIT FOLLOWING:

<p>START</p> <p>BLK</p> <p>RED</p> <p>0.5Ω</p>	<p>STEP#1</p> <p>BLK</p> <p>RED</p> <p>0.5Ω</p>	<p>STEP#2</p> <p>BLK</p> <p>RED</p> <p>0.000</p>
<p>DIODE</p>	<p>DIODE</p>	<p>SHORTED</p>
<p>STEP#4</p> <p>RED</p> <p>BLK</p> <p>0.5Ω</p>	<p>STEP#5</p> <p>RED</p> <p>BLK</p> <p>1.016</p>	<p>STEP#6</p> <p>RED</p> <p>BLK</p> <p>1.016</p>
<p>DIODE</p>	<p>DIODE</p>	<p>HIGH or OPEN</p>
<p>STEP#7</p> <p>BLK</p> <p>RED</p> <p>0.5Ω</p>		
<p>DIODE</p> <p style="text-align: right;">FINISH</p>		

Title	CDI DIVISION OF RAPAIR, INC.
Size	Description
D	336 - 4516
Date:	Monday, May-20-2002 Sheet 1 of 1

Mercury

Two Cylinder Engines 1974-1985 (With the 336-3962 or 336-3996 Stator/Switch Box)

WARNING!! DO NOT START AND RUN THIS ENGINE ON A FLUSHING ATTACHMENT OR EAR MUFFS AND ACTIVATE THE STOP CIRCUIT. This system operates with the orange stop wire normally shorted to ground. When you activate the stop circuit, you open the orange's connection to ground. The resulting backlash into the stator may damage the electronics. You must use the choke to stop the engine. In the water, the back pressure from the exhaust will slow the engine quickly enough to prevent damage to the stator.


Note: The insulator blocks used with this stator are very important. You are strongly advised to closely inspect the points wires and insulator blocks for cracking or arcing. This system operates at a much higher voltage than the normal systems and what would be acceptable on other systems will cause arcing problems.

NO SPARK ON ANY CYLINDER:

1. Disconnect the Orange stop wire and retest. If the ignition system now has spark, the stop circuit has a problem.
2. Use a jumper wire and short the orange (Salmon) wire to ground. If the engine now has spark, replace the stop switch.
3. Disconnect the points wires from the ignition coils and connect a jumper wire to the negative side of the coils. Crank the engine and carefully tap the jumper to engine ground, if the coil sparks – check the points and points wires. If it fails to spark, inspect the ignition coil. You should have either a red, orange or green coil with a bare braided ground wire coming out of the backside of the coil. This bare braided ground wire **MUST** be connected to a clean engine ground. You cannot use a black or blue ignition coil.

NO SPARK ON ONE CYLINDER:

1. Disconnect the points wires from the ignition coils and swap them for a cranking test. Crank the engine over and see if the spark moves to a different coil. If it does, you have a problem in the points, points wire or insulator block for the cylinder not sparking.
2. If the spark remains on the same coil when you swap the points wires and it is the coil where the green wire is coming from the stator, remove the green jumper wire. Swap the green wire coming from the stator from one coil to the other coil. If the spark moves to the other coil, replace the green jumper wire connecting the two coils.
3. Check the ignition coil. You should have approximately 1,000 (1 K ohm) of resistance from the spark plug wire to engine ground.
4. Inspect the ignition coils. You should have either a red, orange or green coil with a bare braided ground wire coming out of the backside of the coil. This bare braided ground wire **MUST** be connected to a clean engine ground. You cannot use a black or blue ignition coil.



Mercury

Two Cylinder Engines 1974-1985 (With the 339-5287 or 339-6222 Switch Box)

NO SPARK ON ANY CYLINDER:

1. Disconnect the Orange stop wire and retest. If the ignition system now has spark, the stop circuit has a problem.
2. Check the stator and trigger resistance and DVA output:

WIRE	Read To	RESISTANCE	DVA
Orange	Engine GND	1600-1800 (800-900 per coil)	180V or more
Brown	White*	140-160	0.5V or more

Note: Some units had used a trigger that has 2 Brown wires instead of a Brown and White.

3. Inspect the ignition coils. You should have either a red, orange or green coil with a bare braided ground wire coming out of the backside of the coil. This bare braided ground wire MUST be connected to a clean engine ground. You cannot use a black or blue ignition coil.
4. Check the ignition coils as follows: Check resistance from + to – terminal reading should be 0.2-1.0 ohms and 800-1100 ohms from the high tension lead to engine ground. There should be no connection from the – terminal to engine ground.
5. Check the flywheel for broken magnets.

ENGINE HAS SPARK BUT WILL NOT RUN:

1. Index the flywheel and check the timing. If it is out by 180 degrees, swap the trigger wires to the switch box.
2. If the timing is off by any other degree, check the flywheel key.

NO SPARK OR INTERMITTENT ON ONE CYLINDER:

1. Check the DVA output between the Green wire and Green/Whites from the switch box, also between the Blue and Blue/White wires while they are connected to the ignition coils. You should have a reading of at least 150V or more. If the reading is low on one cylinder, disconnect the wires from the ignition coil for that cylinder and reconnect them to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading indicates a bad switch box.
2. Connect an inductive tachometer to each cylinder and compare the RPM readings at the RPM where the problem is occurring. If only one cylinder is dropping out, swap the ignition coil locations and retest. If the problem follows a coil, replace the coil. If it stays on the same spark plug, replace the switch box.
3. Check the flywheel magnets to see if one has come loose and moved.

Mercury

Two Cylinder Engines 1974-1985 (With the 332-4911 or 332-4733 Switch Box)

NO SPARK ON ANY CYLINDER:

1. Disconnect the Orange (or Black/Yellow) stop wire and retest. If the ignition system now has spark, the stop circuit has a problem.
2. Check the stator and trigger resistance and DVA output:

WIRE	Read To	RESISTANCE	CDI RESISTANCE	DVA
Blue	Engine GND	3500-5500		180V or more
Red	Engine GND	450-550		20V or more
Brown	White*	140-160		0.5V or more

3. Check the flywheel for broken magnets.

ENGINE HAS SPARK BUT WILL NOT RUN:

1. Index the flywheel and check the timing. If it is out by 180 degrees, swap the trigger wires to the switch box.
2. If the timing is off by any other degree, check the flywheel key.

NO SPARK OR INTERMITTENT ON ONE CYLINDER:

1. Check the DVA output from the switch box on the Green wires while they are connected to the ignition coils. You should have a reading of at least 150V or more. If the reading is low on one cylinder, disconnect the wires from the ignition coil for that cylinder and reconnect them to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading indicates a bad switch box.
2. Connect an inductive tachometer to each cylinder and compare the RPM readings at the RPM where the problem is occurring. If only one cylinder is dropping out, swap the ignition coil locations and retest. If the problem follows a coil, replace the coil. If it stays on the same spark plug, replace the switch box.
3. Check the flywheel magnets to see if one has come loose and moved.

Mercury

Two Cylinder Engines 1979-1996 (With the 332-7452 Switch Box)

NO SPARK ON ANY CYLINDER:

1. Disconnect the Black/Yellow stop wire and retest. If the ignition system now has spark, the stop circuit has a problem.
2. Check the stator and trigger resistance and DVA output:

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Black/Yellow	Engine GND	3250-3650	2200-2400	180V or more
Black/White	Engine GND	150-250	200-250	25V or more
Brown/Yellow	Brown/White	750-1400	925-1050	4V or more
Brown/Yellow	Engine GND	Open	Open	1V or more
Brown/White	Engine GND	Open	Open	1V or more

NO SPARK OR INTERMITTENT ON ONE CYLINDER:

1. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both places. If the reading is low on one cylinder, disconnect the green wire from the ignition coil for that cylinder and reconnect it to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading indicates a bad switch box.

2. Check the trigger resistance and DVA output as shown below:

Wire Color	Check To (Wire Color)	Resistance	DVA Reading
Brown wire	White wire	800-1400 4V or more	Connected
Brown wire	Engine GND	Open	1V or more (*)
White wire	Engine GND	Open	1V or more (*)

(*) This reading can be used to determine if a pack has a problem in the triggering circuit. For instance, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

3. Connect an inductive tach to each cylinder and compare the RPM readings at the RPM where the problem is occurring. If only one cylinder is dropping out, swap the ignition coil locations and retest. If the problem follows a coil, replace the coil. If it stays on the same spark plug, replace the switch box.
4. Check the flywheel magnets to see if one has come loose and moved.

WILL NOT ACCELERATE BEYOND 3000-4000 RPM:

1. Check the stator resistance and DVA output:

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Black/Yellow	Engine GND	3250-3650	2200-2400	180V or more
Black/White	Engine GND	150-250	200-250	25V or more

2. Connect a DVA meter to the Black/White wire/terminal and while under load, run the engine up to the RPM where the problem is occurring. The stator high speed voltage should increase with RPM. If the stator voltage falls off or if it does not increase with RPM, replace the stator.
3. Connect an inductive tach to each cylinder and compare the RPM readings at the RPM where the problem is occurring. If only one cylinder is dropping out, swap the ignition coil locations and retest. If the problem follows a coil, replace the coil. If it stays on the same spark plug, replace the switch box. If both cylinders become intermittent, replace the switch box.

Two Cylinder Engines 1994-1996 (With the 18495A4, A5, A6, A8, A11 or A13 Switch Box)

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wire AT THE PACK and retest. If the engine's ignition now has spark now, the stop circuit has a fault-possibly the key switch, harness or shift switch.
2. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
3. Check the stator resistance and DVA output as given below:

Black Stator

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue	Blue/White	3250-3650	500-600	180V or more
Red	Red/White	75-90	28-32	25V or more

Red Stator

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
White/Green	Green/White	500-700	500-600	180V or more

Red Stator Adapter (Not Available from CDI)

WIRE	Read To	OEM RESISTANCE	DVA
Blue	Engine GND	OPEN	180V or more

NO SPARK OR INTERMITTENT ON ONE CYLINDER:

1. If the cylinders are only misfiring above an idle, connect an inductive an Tachometer to each cylinder in turn and try to isolate the problem cylinder.
2. Check the trigger resistance and DVA output as shown below:

Wire Color	Check To (Wire Color)	Resistance	DVA Reading
Brown wire	White wire	800-1400 4V or more	Connected
Brown wire	Engine GND	Open	1V or more (*)
White wire	Engine GND	Open	1V or more (*)

(*) This reading can be used to determine if a pack has a problem in the triggering circuit. For instance, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

3. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both places. If the reading is low on one cylinder, disconnect the green wire from the ignition coil for that cylinder and reconnect it to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading indicates a bad power pack.

WILL NOT ACCELERATE BEYOND 3000-4000 RPM:

1. Connect an inductive Tachometer to each cylinder in turn and try to isolate the problem. A single cylinder dropping fire will likely be the switch box or ignition coil. All cylinders misfiring usually indicate a bad stator.
2. Connect a DVA meter between the stator's blue wire and blue/white wires. Perform a running test. The DVA voltage should jump up to well over 200V and stabilize. A drop in voltage right before the problem occurs indicates a bad stator. (read the blue wire to engine ground if the engine has a red stator kit installed).
3. Connect a DVA meter between the stator's red wire and red/white wires. The DVA voltage should show a smooth climb in voltage and remain high through the RPM range. A reading lower than the reading on the blue wire indicates a bad stator.
4. If both cylinders become intermittent, replace the switch box.
5. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
6. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.

Two Cylinder Engines 1994-1996 (With the 18495A9, A14, A16, A20, A21 or A30 Switch Box)

NOTE: This engine has a locked trigger arm. Therefore, the timing is controlled by the switch box and is adjusted according to the engine RPM. RPM limiting is done by retarding the timing at high RPM's. Where possible, it is recommended that the ignition system be changed over to either the newer type ignition or the older type of ignition.

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wire AT THE PACK and retest. If the engine's ignition now has spark now, the stop circuit has a fault-possibly the key switch, harness or shift switch.
2. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
3. Check the stator resistance and DVA output as given below:

Stator				
WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue	Black	2900-3500	2200-2600	180V or more connected
Red	Black	100-180	200-250	25V or more connected
Black	Eng Gnd	Open	Open	2V or more connected

NO SPARK OR INTERMITTENT ON ONE CYLINDER:

1. If the cylinders are only misfiring above an idle, connect an inductive an Tachometer to each cylinder in turn and try to isolate the problem cylinder.
2. Check the trigger resistance and DVA output as shown below:

Wire Color	Check To (Wire Color)	Resistance	DVA Reading
Brown wire	White wire	800-1400 4V or more	Connected
Brown wire	Engine GND	Open	1V or more (*)
White wire	Engine GND	Open	1V or more (*)

(*) This reading can be used to determine if a pack has a problem in the triggering circuit. For instance, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

3. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both places. If the reading is low on one cylinder, disconnect the green wire from the ignition coil for that cylinder and reconnect it to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading indicates a bad power pack.

Two Cylinder Engines 1994-1996 (With the 18495A9, A14, A16, A20, A21 or A30 Switch Box)

(Continued)

WILL NOT ACCELERATE BEYOND 3000-4000 RPM:

1. Connect an inductive Tachometer to each cylinder in turn and try to isolate the problem. A single cylinder dropping fire will likely be the switch box or ignition coil. All cylinders misfiring usually indicate a bad stator.
2. Connect a timing light to #1 cylinder and verify that the timing is advancing. Also check to make sure the timing is not retarding too early.
3. Connect a DVA meter between the stator's blue wire and black wires. Perform a running test. The DVA voltage should jump up to well over 200V and stabilize. A drop in voltage right before the problem occurs indicates a bad stator. (read the blue wire to engine ground if the engine has a red stator kit installed).
4. Connect a DVA meter between the stator's red wire and black wires. The DVA voltage should show a smooth climb in voltage and remain high through the RPM range. A reading lower than the reading on the blue wire indicates a bad stator.
5. If both cylinders become intermittent, replace the switch box.
6. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
7. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.

Two Cylinder Engines 1994-2006 (With the 855721A3 & A4 Switch Box)

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wire AT THE PACK and retest. If the engine's ignition now has spark now, the stop circuit has a fault-possibly the key switch, harness or shift switch.
2. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
3. Check the stator and trigger resistance and DVA output as given below:

WIRE	Read To	OEM Ohms	CDI Ohms	DVA
Green/White	White/Green	660-710	350-450	180V minimum connected
Green/White	Eng Gnd	Open	Open	None disconnected
White/Green	Eng Gnd	Open	Open	None disconnected
Brown/White	Brown/Yellow	850-1100	850-1100	4V minimum connected
Brown/White	Eng Gnd	Open	Open	None disconnected
Brown/Yellow	Eng Gnd	Open	Open	None disconnected

NO SPARK OR INTERMITTENT ON ONE CYLINDER:

1. If the cylinders are only misfiring above an idle, connect an inductive an Tachometer to each cylinder in turn and try to isolate the problem cylinder.
2. Check the trigger resistance and DVA output as shown below:

Wire Color	Check To (Wire Color)	Resistance	DVA Reading
Brown/White	Brown/Yellow	850-1100	4V minimum connected
Brown/White	Eng Gnd	Open	1V or more (*)
Brown/Yellow	Eng Gnd	Open	1V or more (*)

(*) This reading can be used to determine if a pack has a problem in the triggering circuit. For instance, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

3. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both places. If the reading is low on one cylinder, disconnect the green wire from the ignition coil for that cylinder and reconnect it to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading indicates a bad power pack.

WILL NOT ACCELERATE BEYOND 3000-4000 RPM:

1. Connect an inductive Tachometer to each cylinder in turn and try to isolate the problem. A single cylinder dropping fire will likely be the switch box or ignition coil.
2. Connect a DVA meter between the stator's Green/White wire and White/Green wires. Perform a running test. The DVA voltage should jump up to well over 200V and stabilize. A drop in voltage right before the problem occurs usually indicates a bad stator.
3. If both cylinders become intermittent, replace the switch box if the stator tests good.
4. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
5. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.

Three Cylinder Engines 1976-1996

Three Cylinder Engines Using a Single Switch Box and Three Ignition Coils

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wire AT THE PACK and retest. If the engine's ignition now has spark, the stop circuit has a fault-check the key switch, harness and shift switch.
2. Disconnect the yellow wires from the stator to the rectifier and retest. If the engine has spark, replace the rectifier.
3. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
4. Check the stator resistance and DVA output as given below:

Flywheel with Bolted-in Magnets

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue Engine	GND	5800-7000	2200-2400	180V or more
Red	Engine GND	135-165	45-55	25V or more

Flywheel with Glued-in Magnets

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue Engine	GND	3250-3650	500-600	180V or more
Red	Engine GND	75-90	28-32	25V or more

Red Stator Kit

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
White/Green	Green/White	500-700	500-600	180V or more
Blue	Engine GND	OPEN		180V or more

NO SPARK OR INTERMITTENT SPARK ON ONE OR MORE CYLINDERS:

1. If the cylinders are only misfiring above an idle, connect a inductive Tachometer to all cylinders and try to isolate the problem cylinders.
2. Check the trigger resistance and DVA output as given below:

Wire Color	Check to Wire Color	Resistance	DVA Reading
Brown wire	White/Black	800-1400 4V or more	Connected
White wire	White/Black	800-1400 4V or more	Connected
Purple wire	White/Black	800-1400 4V or more	Connected
Brown wire	Engine GND	Open	1V or more (*)
White wire	Engine GND	Open	1V or more (*)
Purple wire	Engine GND	Open	1V or more (*)

(*) This reading can be used to determine if a pack has a problem in the triggering circuit. For instance, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

3. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both terminals. If the reading is low on one cylinder, disconnect the green wire from the ignition coil for that cylinder and reconnect it to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading symptom indicates a bad power pack.

ENGINE WILL NOT ACCELERATE BEYOND 3000-4000 RPM:

1. Connect an inductive Tachometer to all cylinders and try to isolate the problem. A single cylinder dropping fire will likely be the switch box or ignition coil. All cylinders misfiring usually indicate a bad stator.
2. Connect a DVA meter to the stator's blue wire and engine ground and do a running test. The DVA voltage should jump up to well over 200V and stabilize. A drop in voltage right before the problem occurs indicates a bad stator. (blue to engine ground if the engine has a red stator kit installed).
3. Connect a DVA meter to the stator's red wire and engine ground and do a running test. The DVA voltage should show a smooth climb in voltage and remain high through the RPM range. A reading lower than the reading on the blue wire indicates a bad stator.

HIGH SPEED MISS:

1. Connect an inductive Tachometer to all cylinders and try to isolate the problem. A high variance in RPM on one cylinder indicates a problem usually in the switch box or ignition coil. Occasionally a trigger will cause this same problem. Check the trigger as described above under "No spark or Intermittent on One or More Cylinders".
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
3. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.
4. Rotate the stator 1 bolt hole in either direction and retest.

WILL NOT IDLE BELOW 1500 RPM:

1. Check the Bias resistance from the Black/White terminal to engine ground. Reading should be 14-15,000 ohms.
2. Check for air leaks.

Four Cylinder Engines (With Ignition Driver Distributors)

WARNING!! DO NOT CONNECT 12VDC TO THE IGNITION MODULE AS DC VOLTAGE WILL BURN OUT THE SWITCH BOX AND IGNITION DRIVER.

NO SPARK ON ANY CYLINDER:

1. Disconnect the orange stop wire AT THE PACK and retest. If the engine's ignition now has spark, the stop circuit has a fault-check the key switch, harness and mercury tilt switch.
2. Check the Ignition Driver resistance and DVA output:

Wire Color	Read to	Function	Resistance	DVA Reading
Red	White wire	Cranking Winding	400 ohms	180V+
Blue	White wire	High Speed Winding	10 Ohms	20V+
Green	Engine Gnd	Pack output	N/A	150V+
White	Common for Ignition Driver (DOES NOT CONNECT TO ENGINE GND)			

3. Check the cranking RPM. A cranking speed of less than 250-RPM will not allow the system to fire properly.

NO SPARK ON ONE OR MORE CYLINDERS:

If only one or two cylinders are not firing on this system, the problem is going to be either in the distributor cap or spark plug wires.

Four Cylinder Engines 1978-1996

Four Cylinder Engines Using a Single Switch Box and Four Ignition Coils

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wires AT THE PACK and retest. If the engine's ignition now has spark, the stop circuit has a fault-check the key switch, harness and mercury tilt switch.
2. Disconnect the yellow wires from the stator to the rectifier and retest. If the engine now has spark, replace the rectifier.
3. Verify the correct flywheel is installed.
4. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
5. Check the stator resistance and DVA output as shown below:

Flywheel with Bolted-in Magnets

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue	Blue/White	5000-7000	2200-2400	180V or more
Red	Red/White	125-155	45-55	25V or more

Flywheel with Glued-in Magnets

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue	Blue/White	3250-3650	500-600	180V or more
Red	Red/White	75-90	28-32	25V or more

Red Stator

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
White/Green	Green/White	500-700	500-600	180V or more
Blue	Blue	OPEN		180V or more
Blue (Each)	Ground	OPEN		180V or more

NO SPARK OR INTERMITTENT SPARK ON ONE OR MORE CYLINDERS:

1. If the cylinders are only misfiring above an idle, connect an inductive Tachometer to all cylinders and try to isolate the problem cylinders.
2. Check the trigger resistance and DVA output as given below:

Wire Color	Check to Wire Color	Resistance	DVA Reading
Purple wire	White wire	800-1400 4V or more	Connected
Brown wire	White/Black wire	800-1400 4V or more	Connected
Purple wire	Engine GND	Open	1V or more (*)
White wire	Engine GND	Open	1V or more (*)
Brown wire	Engine GND	Open	1V or more (*)
White/Black wire	Engine GND	Open	1V or more (*)

(*) This reading can be used to determine if a pack has a problem in the triggering circuit. For instance, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

Note: If #1 and #2, or #3 and #4 are misfiring, check the trigger as described above. The trigger has two coils firing four cylinders. #1 & 2 share a trigger coil and #3 & 4 share a trigger coil. Also, the switch box is divided into two parts. The #1 and #2 cylinders are fired on one side and #3 and #4 are fired from the other side of the switch box. If the trigger tests are okay according to the chart above, but you have two cylinders not firing (either #1 and #2, or #3 and #4), the switch box or stator is bad.

3. If you have two cylinders not firing (either #1 and #2, or #3 and #4), switch the stator leads end to end on the switch box (red with red/white and blue with blue/white). If the problem moves to the other cylinders, the stator is bad. If the problem stayed on the same cylinders, the switch box is likely bad.
4. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both terminals. If the reading is low on one cylinder, disconnect the green wire from the ignition coil for that cylinder and reconnect it to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading symptom indicates a bad power pack.

ENGINE WILL NOT ACCELERATE BEYOND 3000-4000 RPM:

1. Connect an inductive Tachometer to all cylinders and try to isolate the problem. If two cylinders on the same end of the switch box are dropping out, the problem is likely going to be either the switch box or trigger. A single cylinder dropping fire will likely be the switch box or ignition coil. All cylinders misfiring usually indicate a bad stator.
2. Connect a DVA meter to the stator's blue wire and blue/white wires and do a running test. The DVA voltage should jump up to well over 200V and stabilize. A drop in voltage right before the problem occurs indicates a bad stator. (Check from blue to blue if the engine has a red stator kit installed).
3. Connect a DVA meter to the red wire and red/white wires and do a running test. The DVA voltage should show a smooth climb in voltage and remain high through the RPM range. A reading lower than the reading on the blue wires indicates a bad stator.

HIGH SPEED MISS:

1. Connect an inductive Tachometer to all cylinders and try to isolate the problem. A high variance in RPM on one cylinder indicates a problem usually in the switch box or ignition coil. Occasionally a trigger will cause this same problem. Check the trigger as described above under "*No fire or Intermittent on One or More Cylinders*".
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
3. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.

WILL NOT IDLE BELOW 1500 RPM:

1. Index the flywheel and check the timing on all cylinders. If the timing cannot be adjusted correctly or if the timing is off on one cylinder, replace the trigger.
2. Check for air leaks.
3. Check synchronization of the carburetors.

Inline 6 and V6 Carbureted Engines Using Dual Switch Boxes and Six Ignition Coils

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wires AT THE PACK and retest. If the engine's ignition has spark, the stop circuit has a fault-check the key switch, harness and shift switch.
2. Disconnect the yellow wires from the rectifier and retest. If the engine has spark, replace the rectifier.
3. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.

NO SPARK ON ONE BANK (3 OF 6 ON THE INLINE L-6):

1. Check the stator resistance and DVA output as shown below:

9 to 16 Amp Battery Charging Capacity			
WIRE (Read to Engine ground)	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue	5000-7000	2200-2400	180V or more
Blue/White	5000-7000	2200-2400	180V or more
Red	90-200	30-90	25V or more
Red/White	90-200	30-90	25V or more

40 Amp Battery Charging Capacity			
WIRE (Read to Engine ground)	OEM RESISTANCE	CDI RESISTANCE	DVA
Blue	3200-4200	2200-2400	150V or more
Blue/White	3200-4200	2200-2400	150V or more
Red	90-140	90-110	20V or more
Red/White	90-140	90-110	20V or more

2. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both terminals on all cylinders. If the reading is low on one bank and the stator voltage is good, the switch box is usually bad. (Note: A final test to verify which component is bad is to swap the stator leads from one switch box to the other. If the problem moves, the stator is bad. If the same bank still does not fire, the switch box is usually bad.)
3. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.

NO SPARK OR INTERMITTENT SPARK ON ONE OR MORE CYLINDERS:

1. Connect a spark gap tester and verify which cylinders are misfiring. If the cylinders are only misfiring above an idle, connect an inductive Tachometer to all cylinders and try to isolate the problem cylinders.
2. Check the trigger resistance and DVA output as shown below:

<u>BLACK SLEEVE TO</u>	<u>YELLOW SLEEVE</u>	<u>Resistance</u>	<u>DVA Reading</u>
Brown wire	White wire	800-1400	4V or more Connected
White wire	Purple wire	800-1400	4V or more Connected
Purple wire	Brown wire	800-1400	4V or more Connected

Service Note: You should get a high or open resistance reading to engine ground from each wire, but you will get a DVA reading of approximately 1-2 Volts. This reading can be used to determine if a pack has a problem in the triggering circuit. For example, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

3. Check the DVA output on the green wires from the switch box while connected to the ignition coils. Check the reading on the switch box terminal AND on the ignition coil terminal. You should have a reading of at least 150V or more at both terminals. If the reading is low on one cylinder, disconnect the green wire from the ignition coil for that cylinder and reconnect it to a load resistor. Retest. If the reading is now good, the ignition coil is likely bad. A continued low reading symptom indicates a bad power pack.

ENGINE WILL NOT ACCELERATE BEYOND 3000-4000 RPM:

1. Connect an inductive RPM meter to all cylinders and try to isolate the problem. If two or more cylinders on the same bank are dropping out, the problem is likely going to be either the stator or the switch box. A single cylinder dropping fire will likely mean the switch box or ignition coil is defective.
2. Check the stator resistance:

9 to 16 Amp Battery Charging Capacity

<u>WIRE (Read to Engine ground)</u>	<u>OEM RESISTANCE</u>	<u>CDI RESISTANCE</u>
Blue	5000-7000	2200-2400
Blue/White	5000-7000	2200-2400
Red	90-200	30-90
Red/White	90-200	30-90

40 Amp Battery Charging Capacity

<u>WIRE (Read to Engine ground)</u>	<u>OEM RESISTANCE</u>	<u>CDI RESISTANCE</u>
Blue	3400-4200	2200-2400
Blue/White	3400-4200	2200-2400
Red	90-140	90-110
Red/White	90-140	90-110

3. Connect a DVA meter to the Blue wire and do a running test. The DVA voltage should jump up to well over 200V and stabilize. A drop in voltage right before the problem occurs indicates a bad stator. Repeat for the blue/white wire and compare the readings.

<u>WIRE (Read to Engine ground)</u>	<u>CRANKING</u>	<u>1000 RPM</u>	<u>3000 RPM</u>
Blue	100-265	195-265	255-345
Blue/White	100-265	195-265	255-345
Red	25-50	120-160	230-320
Red/White	25-50	120-160	230-320
White/Black*	1-6	3-15	10-30

- This voltage is read with an analog DC volt meter – Not a DVA meter.

4. Check the trigger as follows:

<u>WIRE</u>	<u>Read to</u>	<u>OEM RESISTANCE</u>	<u>CDI RESISTANCE</u>	<u>DVA @ CRANKING</u>
Brown (Black Sleeve)	White (Yellow Sleeve)	1100-1400	800-1000	4V or more
White (Black Sleeve)	Purple (Yellow Sleeve)	1100-1400	800-1000	4V or more
Purple (Black Sleeve)	Brown (Yellow Sleeve)	1100-1400	800-1000	4V or more

Service Note: You should get a high or open resistance reading to engine ground from each wire, but you will get a DVA reading of approximately 1-2 Volts. This reading can be used to determine if a pack has a problem in the triggering circuit. For example, if you have no fire on one cylinder and the DVA trigger reading for that cylinder is low – disconnect the trigger wire and recheck the DVA output to ground from the trigger wire. If the reading stays low – the trigger is bad.

High Speed Miss:

1. Connect an inductive RPM meter to all cylinders and try to isolate the problem. A high variance in RPM on one cylinder usually indicates a problem in the switch box or ignition coil. Occasionally a trigger will cause this same problem. Check the trigger as described above under ‘No fire or Intermittent on One or More Cylinders’.
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
3. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.

Two Cylinder Engines 1996-2006

Engines Using a Combination Switch Box and Ignition Coil (CDM Modules)

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wires from the harness and retest. If the engine's ignition sparks, the stop circuit has a fault- check the key switch, harness and shift switch.
2. Swap the White/Green and Green White stator wire and retest. If the problem moves to the other cylinder, the stator is likely bad.
3. Disconnect one CDM module at a time and using a set of piercing probes and jumper wires- short the stator and trigger wire in the CDM connector to engine ground. Retest. If the other module starts sparking, the CDM you unplugged is bad.
4. Disconnect the yellow wires from the stator to the rectifier and retest. If the engine now has spark, replace the rectifier.
5. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to spark properly.
6. Check the stator resistance and DVA output as follows:

WIRE	Read to	OEM RESISTANCE	CDI RESISTANCE	DVA
White/Green	Green/White	500-700	500-600	180V or more

7. Check the resistance of the CDM as follows:

	Red Meter Lead	Black Meter Lead	Reading
CDM Pin #	A	C	700-1300 Ohms
CDM Pin #	D	A	DIODE*
CDM Pin #	A	D	DIODE*
CDM Pin #	D	B	DIODE*
CDM Pin #	B	D	DIODE*
CDM Pin #	A	B	DIODE*
CDM Pin #	B	A	DIODE*
	High Tension Lead	A	700-1300 Ohms

* Diode readings are to be read one way, then reverse the leads and read again. You should get a low reading in one direction and a higher reading in the other.

NO SPARK OR INTERMITTENT SPARK ON ONE CYLINDER:

1. If the cylinders are only misfiring up above an idle, connect an inductive Tachometer to all cylinders and try to isolate the problem cylinders.
2. Using a set of piercing probes, check the trigger DVA output as shown below:

Wire Color	Check To (Wire Color)	Resistance	DVA Reading
White wire	Engine GND	Open	1V or more
Brown wire	Engine GND	Open	1V or more


3. If # 1 is not sparking, swap the White/Green and Green White stator wire and retest. If the problem moves to the #2 cylinder, the stator is likely bad. If no change, swap locations with #2 and see if the problem moves. If it does, the module is bad. A continued no spark condition on the same cylinder indicates a bad trigger.
4. Check the resistance of the CDM as follows:

	Red Meter Lead	Black Meter Lead	Reading
CDM Pin #	A	C	700-1300 Ohms
CDM Pin #	D	A	DIODE*
CDM Pin #	D	B	DIODE*
CDM Pin #	A	B	DIODE*
	High Tension Lead	A	700-1300 Ohms

* Diode readings are to be read one way, then reverse the leads and read again. You should get a low reading in one direction and a higher reading in the other.

High Speed Miss:

1. Connect an inductive Tachometer to each cylinder in turn and try to isolate the problem. A high variance in RPM on one cylinder usually indicates a problem in the trigger or CDM module.
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
3. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracked or broken magnets.



Three Cylinder Engines 1996-2006 Engines Using CDM Modules

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wires from the harness and retest. If the engine's ignition now sparks, the stop circuit has a fault- check the key switch, harness and shift switch.
2. Disconnect one CDM module at a time and see if the other modules start sparking. If they do, the module you just unplugged is bad.
3. If the bottom two CDM modules are not sparking, swap the connection between the top and middle cylinder. If the middle cylinder starts sparking, replace the top CDM.
4. Disconnect the yellow wires from the stator to the rectifier and retest. If the engine now has spark, replace the rectifier.
5. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to spark properly.
6. Check the stator resistance and DVA output as given below:

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
White/Green	Green/White	500-700	500-600	180V or more

7. Check the resistance of the CDM as follows:

	Red Meter Lead	Black Meter Lead	Reading
CDM Pin #	A	C	700-1300 Ohms
CDM Pin #	D	A	DIODE*
CDM Pin #	A	D	DIODE*
CDM Pin #	D	B	DIODE*
CDM Pin #	B	D	DIODE*
CDM Pin #	A	B	DIODE*
CDM Pin #	B	A	DIODE*
	High Tension Lead	A	700-1300 Ohms

* Diode readings are to be read one way, then reverse the leads and read again. You should get a low reading in one direction and a higher reading in the other.

NO SPARK OR INTERMITTENT SPARK ON ONE OR MORE CYLINDERS:

1. If the cylinders are only misfiring above an idle, connect an inductive Tachometer to all cylinders and try to isolate the problem cylinders.
2. Using a set of piercing probes, check the trigger DVA output as shown below:


Wire Color	Check to Wire Color	Resistance	DVA Reading
Purple wire	Engine GND	Open	1V or more
White wire	Engine GND	Open	1V or more
Brown wire	Engine GND	Open	1V or more

NOTE: These triggers have the bias circuitry internally built-in, therefore you cannot measure the resistance like you can measure on the older engines.

3. If # 1 CDM module is not sparking, disconnect the #2 CDM module and see if the #1 CDM module starts sparking. If it does, the module you just unplugged is bad. If it does not, reconnect #2, then disconnect the #3 CDM module and see if the #1 module starts sparking. If it does, the module you just unplugged is bad.
4. If there is no spark on either # 2 or #3, swap locations with #1 and see if the problem moves. If it does, the module is bad. A continued no spark on the same cylinder indicates a bad trigger.

HIGH SPEED MISS:

1. Connect an inductive Tachometer to all cylinders and try to isolate the problem. A high variance in RPM on one cylinder indicates a problem usually in the trigger or CDM module.
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
3. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.
4. Use the diagram below to help in locating the area where the problem may be. Remember a short in #1 can cause either #2 and #3 not to have spark. By the same reason, a problem in either #2 or #3 can cause #1 not to have spark.



Four Cylinder Engines 1996-2006 Engines Using CDM Modules

NO SPARK ON ANY CYLINDER:

1. Disconnect the black/yellow stop wires from the harness and RPM Limiter. Retest. If the engine's ignition has spark, the stop circuit has a fault-check the key switch, harness and shift switch.
2. Disconnect the yellow wires from the rectifier and retest. If the engine has spark, replace the rectifier.
3. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
4. Check the stator resistance and DVA output as given below:

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
White/Green	Green/White	500-700	500-600	180V or more

5. Check the resistance of the CDM as follows:

	Red Meter Lead	Black Meter Lead	Reading
CDM Pin #	A	C	700-1300 Ohms
CDM Pin #	D	A	DIODE*
CDM Pin #	A	D	DIODE*
CDM Pin #	D	B	DIODE*
CDM Pin #	B	D	DIODE*
CDM Pin #	A	B	DIODE*
CDM Pin #	B	A	DIODE*
	High Tension Lead	A	700-1300 Ohms

Note: Diode readings are to be read one way, then reverse the leads and read again. You should get a low reading in one direction and a higher reading in the other.

NO SPARK OR INTERMITTENT SPARK ON ONE OR MORE CYLINDERS:

1. If the cylinders are only misfiring above an idle, connect an inductive RPM meter to all cylinders and try to isolate the problem cylinders.
2. Disconnect the CDM's one at a time and see if you get spark back on the problem cylinders.
3. Using a set of piercing probes, check the trigger DVA output as given below:


Wire Color	Check to Wire Color	Resistance	DVA Reading
Purple wire	Engine GND	Open	3V or more
White wire	Engine GND	Open	3V or more
Brown wire	Engine GND	Open	3V or more
White/Black wire	Engine GND	Open	3V or more

NOTE: These triggers have the bias circuitry internally built-in, therefore you cannot measure the resistance like you can measure on the older engines. In addition, these engines use four triggering coils versus the two triggering coils used on the older engines.

4. Disconnect one of the CDM modules that are firing one at a time and see if the dead CDM starts firing. If it does, the CDM you just unplugged is bad.

High Speed Miss:

1. Connect an inductive RPM meter to all cylinders and try to isolate the problem. A high variance in RPM on one cylinder usually indicates a problem in the switch box or ignition coil. Occasionally a trigger will cause this same problem. Check the trigger as described above under "*No spark or intermittent spark on any cylinder*".
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
3. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.
4. Use the wiring diagram below as an aid in locating areas where problems may occur. Remember a short in either #1 or #2 can cause either #3 and #4 not to have spark.



Six Cylinder Engines

1996-2005 2.0L and 2.5 L Engines Using CDM Modules

NO SPARK ON ANY CYLINDER:

1. Inspect the spark plug wires, boots and spark plugs. Check for chafing on the wiring and harnesses.
2. Clean and inspect CDM ground wire connection to engine ground
3. Disconnect the Black/Yellow stop wires from the harness and RPM Limiter. Retest. If the engine's ignition now has spark, the stop circuit has a fault-check the key switch, harness and shift switch. If there is still no spark, disconnect the CDM's one at a time and see if you get spark back on the other cylinders. A shorted stop circuit in one CDM will prevent ALL cylinders from sparking.
4. Disconnect the yellow wires from the rectifier and retest. If the engine has spark, replace the rectifier.
5. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
6. Check the stator resistance and DVA output as given below:

WIRE	Read To	OEM RESISTANCE	CDI RESISTANCE	DVA
White/Green	Green/White	500-700	500-600	180V or more

7. Check the resistance of each of the CDM's as follows:

	Red Meter Lead	Black Meter Lead	Reading
CDM Pin #	A	C	700-1300 Ohms
CDM Pin #	D	A	DIODE*
CDM Pin #	A	D	DIODE*
CDM Pin #	D	B	DIODE*
CDM Pin #	B	D	DIODE*
CDM Pin #	A	B	DIODE*
CDM Pin #	B	A	DIODE*
	High Tension Lead	A	700-1300 Ohms

Note: Diode readings are to be read one way, then reverse the leads and read again. You should get a low reading in one direction and a higher reading in the other.

NO SPARK OR INTERMITTENT SPARK ON ONE OR TWO CYLINDERS:

1. Inspect the spark plug wires, boots and spark plugs. Check for chafing on the wiring and harnesses
2. Clean and inspect CDM ground wire connection to engine ground.
3. If the cylinders are only misfiring above an idle, connect an inductive RPM meter to all cylinders and try to isolate the problem cylinders.
4. Using a set of piercing probes, check the trigger Resistance and DVA output as given below:

Wire Color	Check to Wire Color	OEM Resistance	CDI Resistance	DVA Reading
Purple wire	Blue	1100-1400	850-1050	4V or more
White wire	Red	1100-1400	850-1050	4V or more
Brown wire	Yellow	1100-1400	850-1050	4V or more

High Speed Miss:

1. Connect an inductive RPM meter to all cylinders and try to isolate the problem. A high variance in RPM on one cylinder usually indicates a problem in the CDM module.
2. Perform a high-speed shutdown and read the spark plugs. Check for water. A crack in the block can cause a miss at high speed when the water pressure gets high, but a normal shutdown will mask the problem.
3. Remove the flywheel and check the triggering and charge coil flywheel magnets for cracks or broken magnets.
4. Index the flywheel and check the timing on ALL cylinders. On carbureted models, the control module rev limit function starts to retard timing in sequence (2, 3, 4, 5, 6, 1) at 5800-6000 RPM. The control module will retard the timing each cylinder up to 30 degrees (starting with #2) and then stop firing that cylinder if the RPM is still above the limit. It will continue to retard, then shut down each cylinder until the engine drops below the limit.

NO SPARK OR INTERMITTENT SPARK ON #1, #2 and #3 OR #4, #5 and #6 CYLINDERS:

1. Check the cranking RPM. A cranking speed less than 250-RPM will not allow the system to fire properly.
2. Disconnect the CDM's one at a time and see if you get spark back on the problem cylinders.
3. Check the stator resistance and DVA output as given below:

WIRE	Read To	OEM	CDI	DVA
White/Green	Green/White	500-700 ohms	500-600 ohms	180V or more connected
White/Green	Engine Gnd	Open	Open	180V or more connected
White/Green	Engine Gnd	Open	Open	Less than 2 V disconnected
Green/White	Engine Gnd	Open	Open	180V or more connected
Green/White	Engine Gnd	Open	Open	Less than 2 V disconnected


3. Using a set of piercing probes, check the trigger Resistance and DVA output as given below:

Wire Color	Check to Wire Color	OEM Resistance	CDI Resistance	DVA Reading
Purple wire	Blue	1100-1400	850-1050	4V or more
White wire	Red	1100-1400	850-1050	4V or more
Brown wire	Yellow	1100-1400	850-1050	4V or more

4. Using a set of piercing probes, check the trigger voltage going to the CDM's:

Wire Color	Check to Wire Color	OEM Resistance	CDI Resistance	DVA Reading
Purple wire	Engine GND	Open	Open	3V or more
White wire	Engine GND	Open	Open	3V or more
Brown wire	Engine GND	Open	Open	3V or more
Blue wire	Engine GND	Open	Open	3V or more
Red wire	Engine GND	Open	Open	3V or more
Yellow wire	Engine GND	Open	Open	3V or more

5. The connection guide below will assist you in locating areas where problems can occur. Remember a short in either #1, #2 or #3 can cause either # 4, #5 and #6 not to have spark.



CDI ELECTRONICS

(DVA) PEAK READING VOLTAGE AND RESISTANCE CHARTS

NOTICE: These charts were compiled using the CDI 511-9773 Peak Adapter with a shielded Digital Multimeter.

NOTE: The resistance readings are given for a room temperature of 68°F. Higher temperatures will cause a slightly higher resistance reading. DVA readings should always be taken with everything hooked up with the exception of the kill circuit.

The CDI peak reading voltage adapter is specifically designed to work with shielded Digital Multimeters. This adapter will simplify the testing of electronic ignition systems, stators, sensors and charging systems. The DVA readings will be approximately the same as any other DVA meter and the specifications listed in the service manuals can be followed without problems (Hopefully a little easier to you).

The CDI piercing probe set (511-9770) and the pack load resistor (511-9775) are highly recommended for use with this adapter.

INSTRUCTIONS

1. Plug the adapter into the shielded Digital Multimeter with the (+) rib side pin in the (V, Ohms) jack and the other pin in the (COM) jack.
2. Set the digital voltmeter to DC Volts (the purpose of the adapter is to convert and *store* the voltage so that it can be read by a meter).
3. Connect the probes to the component to be measured.

*NOTE: The adapter will **automatically compensate for polarity** and all readings will be peak voltage.*

See the following pages for readings of Chrysler, Force, Mercury, OMC (Johnson/Evinrude), OMC Sea Drive and Yamaha engines. Other ignitions can be tested using test results given by the manufacturer of the equipment or by comparing a known good system to a suspect one. Please forward any additional readings you would like to have included in future printings.

Mercury DVA (Peak Reading) Voltage and Resistance Chart

Please note that all DVA readings are minimum voltages measured at cranking speed, not while the engine is running.													
HP	Year	Model	Ignition	Stator				Trigger			Ignition Coil		
		Serial #	Part	Ohms		DVA		Reading	Ohms	DVA	Reading	Primary	Output
		Number	Low Spd	Hi Sp	Low	Hi	Colors	Ohms	Out	Colors	Ohms		
											3200-3800	120-180	180
4	1972-1975	3296137 - 4107219	336-4516	3600-5500	450-550	180V+		Green to Eng Gnd	N/A	N/A	Points Brn & Wht	0.2-1.0	800-1100
4	1976-1980	9075839 - 5595531	<u>339-6222</u> 114-6222	1600-1800 (800-900 per coil)		180V+		Orange to Eng Gnd	140-160	0.5V+	Brn to Brn or Brn to Wht	0.2-1.0	800-1100
4/4.5	1980-1989	5595532 - A855096	336-4516	3600-5500	450-550	180V+		Green to Engine Gnd	N/A	N/A	Points Brown & White	0.2-1.0	800-1100
6/8/9.9/10	1986-1996	A197112 - OG289100	<u>332-7452</u> 114-7452K1	3200-3800 2200-2600*	120-180 225-300*	180 V+	20V+	Blk/Yel (LS) Blk/Wht(HS) to Eng Gnd	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
6/8/10/15/20/25	1995-2006	OG760299 -1B000001	<u>855713</u> 114-5713	370-445		180V+		Green/White to White/Green	650-850	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
9.8/20	1972-1973	3226958-37956658	336-4516	3600-5500	450-550	180V+		Green to Engine Gnd	N/A	N/A	Points Brown & White	0.2-1.0	800-1100
9.8	1974-1985	3795659-5206549	<u>339-6222</u> 114-6222	1600-1800 (800-900 per coil)		180V+		Orange to Eng Gnd	750-1400	0.5V+	Brn to Brn or Brn to Wht	0.2-1.0	800-1100
15 20 25	1988-1993	OB238464-OG044365	<u>332-7452</u> 114-7452K1	3200-3800 2200-2600*	120-180 225-300*	180 V+	20V+	Blk/Yel (LS) Blk/Wht(HS) to Eng Gnd	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
15 20 25	1994-1996	OG044027 - OG437999	<u>18495A30</u> 114-4952K1	3200-3800 2200-2600*	120-180 225-300*	180 V+	20V+	Blue to Black Red to Black	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
15/20	1996-1997	OG438000 - OG760299	<u>332-7452</u> 114-7452K1	3200-3800 2200-2600*	120-180 225-300*	180 V+	20V+	Blk/Yel (LS) Blk/Wht(HS) to Eng Gnd	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
18/20 25 XD	1979-1987	5837437-OB114230	<u>332-7452A3</u> 114-7452A3	3200-3800 2200-2600*	120-180 225-300*	180 V+	20V+	Blk/Yel (LS) Blk/Wht(HS) to Eng Gnd	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
20	1973-1977	3537531-4709592	<u>332-4911</u> 114-4911	3500-5500	450-550	180 V+	20V+	Blue and Red to Engine Gnd	N/A	N/A	Brn to Wht	0.2-1.0	800-1100
20/25	1980-1993	5705532-OG044026	<u>332-7452</u> 114-7452K1	3200-3800 2200-2600*	120-180 225-300*	180 V+	20V+	Blk/Yel (LS) Blk/Wht(HS) to Eng Gnd	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
35	1984-1989	6445653-OB393190	<u>332-7452</u> 114-7452K1	3200-3800 2200-2600*	120-180 225-300*	180 V+	20V+	Blk/Yel (LS) Blk/Wht(HS) to Eng Gnd	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
40	1970-1971	2874704-3336237	<u>332-4172</u> 332-4172	3200-3800 2200-2600*	45-55 45-55*	180 V+	20V+	Blue and White to Engine Gnd	750-1400	0.5V+	Brn to Wht	0.2-1.0	800-1100
40	1972-1981	3336258 - 5823917	338-4733 <u>332-4911</u> 338-4733 114-4911	5000-7000 2200-2500*	180-220 45-55*	180 V+	20V+	Blue to Eng Gnd Red to Eng Gnd	750-1400	0.5V+	Brn/Wht to Brn/Yellow	0.2-1.0	800-1100
40	1982-1984	5283918-6999999	<u>332-7452</u> 114-7452K1	3200-3800 2200-2600*	150-200 225-300*	180 V+	20V+	Blk/Yel (LS) Blk/Wht(HS) to Eng Gnd	750-1400	0.5V+	Brn/Yel to Brn/Wht	0.2-1.0	800-1100
40-45 4 CYL NOTE 2	1989-1996	C159200-OG291031	<u>332-5772</u> 114-5772	3250-3650 2200-2400*	75-90 28-32*	180 V+	20V+	Blue to Bl/Wht Red to Red/Wht	750-1400	4V+	Brn to Wht/Blk Purple to White	0.2-1.0	800-1100
45-80 3 CYL NOTE 3	1989-1996	C159200-OG291031	18495 114-4953	3250-3650 500-700*	75-90 28-32*	180 V+	20V+	Blue to Eng Gnd Red to Eng Gnd	750-1400	4V+	Wht/Blk to Brn, Wht and Purple	0.2-1.0	800-1100
40-125	1997-2001	OG531301 - OG980599	<u>827509</u> 114-7509	660-710 450-600*		180V+		Green/White to White/Green	Open	0.5V+	Gnd to Wht/Blk, Wht/Yel, Blue/Wht	N/A	<u>900-1100</u> 2100-2400
50	1970-1975	2858814-4357639	333-3213	380-420	9-11	180 V+	20V+	Red to White Blue to White	Ignition Driver	N/A	Not Applicable	Does not apply	Does not apply
50	1976-1985	4357640-6586624	<u>332-5772</u> 114-5772	5800-7000 2200-2400*	135-165 30-90*	180 V+	20V+	Blue to Blue/Wht Red to Red/Wht	800-1400	4V+	Brn to Wht/Blk Purple to White	0.2-1.0	800-1100
50	1985-1990	6586625-OD000749	<u>332-7778</u> 114-7778	3250-3650 2200-2400*	75-90 28-32*	180 V+	20V+	Blue to Eng Gnd Red to Eng Gnd	800-1400	4V+	Wht/Blk to Brn, Wht and Purple	0.2-1.0	800-1100
50-60	1991-1996	OD000750-OG589999	<u>19052</u> 114-9052	3250-3650 500-700*	75-90 28-32*	180 V+	20V+	Blue to Gnd Red to Gnd	800-1400	4V+	Wht/Blk to Brn, Wht, Pur	0.2-1.0	800-1100

Mercury

DVA (Peak Reading) Voltage and Resistance Chart

Please note that all DVA readings are minimum voltages measured at cranking speed, not while the engine is running.

50-60 65 Jet	1997- 2001	OG590000- OG980600	<u>827509</u> 114-7509	<u>660-710</u> 450-600*	180V+		Green/White to White/Green	Open	1.5V +	Gnd to Wht/Blk, Wht/Yel, Blue/Wht	N/A	<u>900- 1100</u> 2100- 2400
65	1968	2309311- 2452709	333-3213	380-420 9-11	180V+	20V +	Red to White Blue to White	Ignition Driver	N/A	Not Applicable	N/A	N/A
65	1976- 1979	4382057- 4571651	<u>332-7778</u> 114-7778	<u>3250-3650</u> 2200- 2400*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Pur	0.2- 1.0	800- 1100
65	1994- 1996	OD283222- OG437999	<u>18495</u> 114-4953	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Pur	0.2- 1.0	800- 1100
65 Jet	1992- 1995	OE009500- OE138599	<u>18495</u> 114-4953	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Pur	0.2- 1.0	800- 1100
70	1977- 1993	4571652- OD283221	<u>332-7778</u> 114-7778	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Purple	0.2- 1.0	800- 1100
75	1984- 1988	643901- OB279480	<u>332-5772</u> 114-5772	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Bl/Wht Red to Red/Wht	800- 1400	4V+	Brn to Wht/Blk Purple to White	0.2- 1.0	800- 1100
80	1978- 1983	4831999- 6432900	<u>332-5772</u> 114-5772	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Bl/Wht Red to Red/Wht	800- 1400	4V+	Brn to Wht/Blk Purple to White	0.2- 1.0	800- 1100
80	1987- 1988	OA966142- OB209468	<u>332-7778</u> 114-7778	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Purple	0.2- 1.0	800- 1100
90 Inline 6	1979- 1986	5299506- OB110053	<u>332-7778</u> 114-7778	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Gnd Bl/Wht to Gnd. Red to Gnd Red/Wht to Gnd	800- 1400	4V+	NOTE 1	0.2- 1.0	800- 1100
90 3 CYL NOTE 2	1987- 1992	OA996142- OC221999	<u>332-7778</u> 114-7778	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Purple	0.2- 1.0	800- 1100
90 3 CYL NOTE 3	1989- 1996	OC222000- OG437999	<u>18495</u> 114-4953	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Purple	0.2- 1.0	800- 1100
90 Sport Jet	1995- 1997	OE141089- OE315900	<u>18495</u> 114-4953	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Eng Gnd Red to Eng Gnd	800- 1400	4V+	Wht/Blk to Brn, Wht and Purple	0.2- 1.0	800- 1100
100	1988- 1996	OB209468- OG437999	<u>332-5772</u> 114-5772	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Bl/Wht Red to Red/Wht	800- 1400	4V+	Brn to Wht/Blk Purple to White	0.2- 1.0	800- 1100
105 Jet	1992- 1996	OD082000- OG840500	<u>332-7778</u> 114-7778	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Gnd Bl/Wht to Gnd Red to Gnd Red/Wht to Gnd	800- 1400	4V+	NOTE 1	0.2- 1.0	800- 1100
115 6 Cyl	1979- 1989	5314656- OC09999	<u>332-7778</u> 114-7778	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Gnd Bl/Wht to Gnd Red to Gnd Red/Wht to Gnd	800- 1400	4V+	NOTE 1	0.2- 1.0	800- 1100
115/125 4 Cyl	1989- 1996	OC10000- OG437999	<u>332-5772</u> 114-5772	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Bl/Wht Red to Red/Wht	800- 1400	4V+	Brn to Wht/Blk Purple to White	0.2- 1.0	800- 1100
120 Sport Jet	1995	OE080400- OE141088	<u>332- 826866</u> 114-6866	<u>3250-3650</u> 500-700*	180V+	20V +	Blue to Bl/Wht Red to Red/Wht	800- 1400	4V+	Brn to Wht/Blk Purple to White	0.2- 1.0	800- 1100
120 Sport Jet	1996- 2000	OE141089- OE384499	<u>827509</u> 114-7509	<u>500-700</u> 400-600*	180V+		Green/White to White/Green	Open	1.5V +	Gnd to Wht/Blk, Wht/Yel, Blue/Wht, Brn/Wht	N/A	<u>900- 1100</u> 2100- 2400
135-200 6 CYL 9-15 AMP	1978- 1985	4868998- OA904646	<u>332-7778</u> 114-7778	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Gnd Bl/Wht to Gnd Red to Gnd Red/Wht to Gnd	800- 1400	4V+	NOTE 1	0.2- 1.0	800- 1100
135-275 2.0L, 2.4L 16 AMP	1985- 1988	OA904647- OC100860	<u>332-7778</u> 114-7778	<u>5800-7000</u> 2200- 2400*	180V+	20V +	Blue to Gnd Bl/Wht to Gnd Red to Gnd Red/Wht to Gnd	800- 1400	4V+	NOTE 1	0.2- 1.0	800- 1100
175/210 Sport Jet 16 AMP	1997- 2005	<u>398-9873</u> 174-9873-16	<u>18495</u> 114-4953	<u>1000-1600</u> 450-600*	180V+	20V +	Blue to Gnd Bl/Wht to Gnd Red to Gnd Red/Wht to Gnd	800- 1400	4V+	NOTE 1	0.2- 1.0	800- 1100
135-275 2.0L, 2.4L 2.5L 40 AMP	1989- 2005	OC100861- OG840500	<u>332-7778</u> 114-7778	<u>3200-4200</u> 2100- 2400*	180V+	20V +	Blue to Gnd Bl/Wht to Gnd Red to Gnd Red/Wht to Gnd	1100 - 1400	4V+	NOTE 1	0.2- 1.0	800- 1100
225 Carb 250 EFI 3.0L	1996- 2004	OD280813- OG840500	<u>827509</u> 114-7509	900-1100	180V+		Green/White to White/Green	Open	1.5V +	Gnd to Wht/Blk , Wht/Yel, Blue/Wht, Brn/Wht, Red/Wht, Pur/Wht	N/A	<u>900- 1100</u> 2100- 2400

Gnd = Engine ground
Bl/Wht = Blue/White

Blk = Black
Wht/Blk = White/Black

Blk/Wht = Black/White Stripe
Brn/Yel = Brown/Yellow Stripe

* Manufactured by CDI Electronics
Red/Wht = Red/White
Blk/Yel = Black/Yellow Stripe

YAMAHA DVA and RESISTANCE CHARTS

HP	YEAR	# Cyl	ST K	MDL	STATOR						TRIGGER			CDI Out	IGNITION COIL		SPK PLG
					OHMS		DVA		CHECK POINTS		OHMS	DV A	CHECK POINTS		OHMS +/- 10%		CAP
					L S	HS	L S	H S	HS	LS	Ohms	DV A			Pri	Sec	
2	1984-2004	1	2		320-390				Brown to Gnd		N/A	N/A	N/A		0.21	3.2K	
2.5	2003-2004	1	4	F										.56-.84	11.6 K - 17.4 K	4-6 K	
3	1984-2002	1	2		250-300	100		Brown to BLK		30-36 LS 280- 340 HS		Red/White to BLK Green/Wht to BLK		0.1	2.6 K		
4	1984-1999	1	2		250-300	100		Brown to BLK		30-36 LS 280- 340 HS		White/Red to BLK White/Grn to BLK		0.1	3.1 K	None	
4	1999-2004	1	2			126		TCI to Gnd						.56-.84	11.6 K - 17.4 K	4.9-5.1 k	
5	1984-2002	1	2		250-300	100		Brown to BLK		30-36 LS 280- 340 HS		White/Red to BLK White/Grn to BLK		0.3	3.1 K	None	
6	1984-2000	2	2		81-99	100		Brown to BLK		92-111		White/Red to Blk		0.1	3.5 K	None	
6/8	2001-2004	2	4	F	81-99	100		Brown to BLK		92-111		White/Red to Blk		0.1	7.8 K	None	
8	1986-2004	2	2		81-99	100		Brown to BLK		92-111		White/Red to Blk		0.3	3.5 K	None	
9.9	1984-1992	2	2		81-99	100		Brown to BLK		92-111		White/Red to Blk		0.3	3.5 K	None	
9.9	1993-1995	2	2		81-99	100		Brown to BLK		92-111		White/Red to Blk		0.3	5.4 K	None	
9.9/15	1996-2004	2	2		280-340	105		Brown to BLK		396- 484		White/Red to Blk		0.6	2.1 K	None	
9.9	1984-1990	2	4	F/FT/ T	300-400	90		Brown to Blue		280- 340	2.5	White/Red to Blk		0.5	3.4 K	None	
9.9	1991-2004	2	4	F/FT/ T	300-400	90		Brown to Blue		280- 340	2.5	White/Red to Blk		0.5	4.1K	None	
15	1984-1995	2	2		81-99			Brown to BLK		92-111		White/Red to Blk		0.3	5.4 K	None	
15	1998-2004	2	4	F	272-408	135		Brown to Blue		234- 348	4	White/Red to Blk	115	0.5	4.91 K	None	
20	1996-1997	2	2		340-420	125		Brown to Blue		310- 390	5.5	White/Red to Blk White/Blk to Blk	105	0.5	3.2 K	None	
25	1984-1987	2	2		120-150	190		Brown to Blue		12-16	5	White/Red to Blk White/Blk to Blk	210	0.5	3.5 K	None	
25	1988-1993	2	2		200-275	190		Brown to BLK		90-120	5	White/Red to Blk White/Blk to Blk	210	0.5	3.5 K	None	
25	1994-2004	2	2		340-420	125		Brown to Blue		310- 390	5.5	White/Red to Blk White/Blk to Blk	105	0.5	3.2 K	None	
25	1996-2002	3	2		340-420	175		Brown to Blue		310- 390	4	White/Red to Blk White/Blk to Blk White/Grn to Blk	135	0.5	6.3 K	None	
25	1990-1992	2	2	C	200-275	190		Brown to BLK		90-120	5	White/Red to Blk	210	0.5	3.5 K	None	
25	1993-1995	2	2	C	200-275	190		Brown to BLK		90-120	5	White/Red to Blk	210	0.5	5.4 K	None	
25	1996-1997	2	2	C	200-275	190		Brown to BLK		90-120	5	White/Red to Blk	210	0.5	8.5 K	None	
25	1998-2004	2	4	F	660-710	190		Grn/Wht to Wht/Grn		300- 350	6	Red to Wht	100	0.5	4.1 K	None	
30	1984-1986	2	2		120-150	190		Brown to Blue		12-16	5	White/Red to Blk	210	0.5	3.5 K	None	
30	1987-2002	3	2		280-330	175		Brown to Blue		310- 390	4	White/Red to Blk White/Blk to Blk White/Grn to Blk	135	0.5	6.3K	None	
30	1989-1992	2	2	C	120-150	190		Brown to Blk		12-16	5	White/Red to Blk	210	0.5	3.5 K	None	
30	1993-1996	2	2	C	400-490	125		Brown to Blue		310- 390	4	White/Red to Blk White/Blk to Blk	105	0.5	3.2 K	None	
30	1997	2	2	C	340-420	125		Brown to Blue		310- 390	4	White/Red to Blk White/Blk to Blk	105	0.5	3.2 K	None	

YAMAHA DVA and RESISTANCE CHARTS

HP	YEAR	# Cyl	STK	MD L	STATOR						TRIGGER			CDI Out	IGNITION COIL		SPK PLG
					OHMS		DVA		CHECK POINTS		OHMS	DVA	CHECK POINTS		OHMS +/- 10%		CAP
					L S	HS	LS	H S	HS	LS	Ohms	DVA			Primary	Sec	
30	2001-2004	2	4	F	600-720		193		Grn/Wht to Wht/Grn		270-330	6	White/Red to Blk	151	0.5	4.1 K	None
40/50	1984-1988	3	2		180-250		175		Brown to Blue		310-390	4	White/Red, White/Blk, White/Grn to Blk	135	0.5	6.3K	
40/50	1989-1994	3	2		280-330		200		Brown to Blue		180-220	4	White/Red, White/Blk, White/Grn to Blk	175	0.5	3.2 K	None
40/50	1995-2004	3	2		400-510		145		Brown to Blue		180-240	3	White/Red, White/Blk, White/Grn to Blk	125	0.5	3.2 K	None
40	1989-1997	2	2	C	120-140		125		Brown to Blue		12-16	5.5	White/Red to Blk	115	0.5	3.5 K	None
40	1998-2002	3	2	C	400-510		145		Brown to Blue		180-220	4	White/Red, White/Blk, White/Grn to Blk	125	0.5	3.2 K	None
40	1999	4	4	F	300-380		140		Brown to Blue		375-475	7	Red/Wht to White/Blk	105	0.5	4.1 K	4-6 K
40	2000-2004	3	4	F	600-710		193		Grn/Wht to Wht/Grn		270-330	6	Red/Wht to Blk	151	0.5	2.7-3.7K	4-6 K
48	1995-2000	2	4	E	81-99				Brown to BLK		92-111		White/Red to Blk		0.3	5.4K	None
50	1999-2002	3	2	C	420-510		145		Brown to Blue		180-240	3	White/Red, White/Blk, White/Grn to Blk	125	0.5	3.2 K	None
50	1995-2000	4	4	F	300-380		137		Brown to Blue		375-475	3.5	Red/Wht to White/Blk	150	0.5	4.1 K	3.8-5.7 K
50	1996-2000	4	4	F	300-380		137		Brown to Blue		375-475	3.5	Red/Wht to White/Blk	150	0.5	4.1 K	3.8-5.7 K
50	2001-2004	4	4	F	272-408		144		Brown to Blue		396-594	6.3	Red/Wht to White/Blk	126	0.078-0.106	3.5-4.7 K	3.8-5.7 K
55	1989-1994	2	2	C	200-260		135		Brown to Blue		70-88 23-29	2	White/Red, White/Blk, Yel to Blk	150	0.5	3.1 K	None
55	1995	2	2	C	200-260		135		Brown to Blue		280-360	2	White/Red, White/Blk to Blk	150	0.5	3.1 K	None
60	1991-2000	3	2		145-190		140		Brown to Blue		110-150	2.5	White/Red, White/Blk, White/Grn to Blk	100	0.5	3.2 K	None
60	1992-1999	2	2	P	150-190		120		Brown to Blue		270-330	2.5	White/Red to White/Blk	105	0.5	4.1 K	None
60	1996-2002	2	2	C	150-190		120		Brown to Blue		270-330	2.5	White/Red to White/Blk	105	0.5	4.1 K	None
60	2001-2004	3	2		150-190		150		Brown to Blue		270-330	2.5	White/Red to White/Blk	105 on #1 & #3 at idle (0 on #2), 145 on all at 1500 RPM	0.5	4.1 K	None
60	2002-2004	4	4	F/T	272-408		144		Brown to Blue		396-594	6.3	Red/Wht to White/Blk	126	0.078-0.106	3.5-4.7 K	3.8-5.7 K
70	1984-1991	3	2		145-190		140		Brown to Blue		110-150	2.5	White/Red, White/Blk, White/Grn to Blk	100	0.5	3.2 K	
70	1992-2004	3	2		150-190		150		Brown to Blue		270-330	2.5	White/Red to White/Blk	105 on #1 & #3 at idle (0 on #2), 145 on all at 1500 RPM	0.5	4.1 K	None

YAMAHA DVA and RESISTANCE CHARTS

HP	YEAR	# Cyl	STK	MDL	STATOR						TRIGGER			CDI Out	IGNITION COIL		SPK PLG
					OHMS		DVA		CHECK POINTS		OHMS	DVA	CHECK POINTS		OHMS +/- 10%		CAP
					L Spd	HSpd	LS	HS	HS	LS	Ohms	DVA			Primary	Sec	
75	1994-1996	3	2	C	900-1100	105-140	85	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to Wht/Yel Wht/Gm to Wht/Blk	95	0.5	4.5K	
75	1998-1999	3	2	C	191-288	64-96	55	90	Brn to Red	Blue to Red	241-362	7	White/Red to White/Blk	105 on #1 & #3 at idle (0 on #2), 145 on all at 1500 RPM	0.5	4.0 K	None
75	1995-1996	3	2	E	900-1100	105-140	85	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to White/Gm Wht/Blk to Wht/Gm	95	0.5	4.8K	None
75	1996-1999	3	2	P	900-1100	105-140	85	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to White/Yel Wht/Gm to Wht/Blk	95	0.5	4.8 K	None
75	1997-2000	3	2	E	480-600	50-70	105	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to White/Gm Wht/Blk to Wht/Gm	105	0.5	4.1K	None
75/90	2003-2004	4	4	F	?	?	?	?	?	?	396-594	2.7	White/Red to Blk White/Blk to Blk	107	0.5	4.1 K	#1 - 7.6K #2 - 5.6 K #3 - 6.3 K #4 - 7.2 K
80	1997	3	2	C	220-270	70-90	100	60	Brn to Red	Blue to Red	241-362	5	White/Red to Wht/Blk	130	0.5	4.1 K	None
80/100	1999-2002	4	4	F	?	?	?	?	?	?	396-594	2.7	White/Red to Blk White/Blk to Blk	107	0.5	4.1 K	#1 - 7.6K #2 - 5.6 K #3 - 6.3 K #4 - 7.2 K
85	1989-1996	4	2	C	900-1100	105-140	85	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to White/Yel Wht/Gm to Wht/Blk	95	0.5	4.8 K	None
90	1984-1989	4	2		765-935	105-135	85	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to White/Yel Wht/Gm to Wht/Blk	95	0.5	2.5 K	None
90	1990-1991	4	2		900-1100	105-140	85	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to White/Yel Wht/Gm to Wht/Blk	95	0.5	4.8 K	None
90	1992-2004	3	2		220-270	70-90	100	60	Brn to Red	Blue to Red	241-362	5	White/Red to White/Blk	130	0.5	4.1 K	None
115	1984-1988	4	2	B/P/S	625-820	62-79	160	45	Brn to Red	Blue to Blk/Red	280-460	2.5	Wht/Red to White/Yel Wht/Gm to Wht/Blk	95	0.5	3.8 K	None
115	1994-2000	4	2	C	900-1100	105-140	85	45	Brn to Blue	Blue to Blk/Red	320-400	2.5	Wht/Red to White/Yel Wht/Gm to Wht/Blk	95	0.5	2.5 K	4-6 K
115	2000-2004	4	4	F	?	?	?	?	?	?	?	3	White/Red to Blk White/Blk to Blk	5			None

YAMAHA DVA and RESISTANCE CHARTS

HP	YEAR	# Cyl	STK	MDL	STATOR						TRIGGER			CDI Out	IGNITION COIL		SPK PLG
					OHMS		DVA		CHECK POINTS		OHMS	DVA	CHECK POINTS		Primary	Sec	CAP
					L Spd	HSpd	LS	HS	HS	LS	Ohms	DVA					
130	1984-1989	4	2		900-1100	105-140	85	45	Brn to Blue	Red to Blue	290-370	2.5	Wht/Red to White/Yel Wht/Grn to Wht/Blk	95	0.5	4.8 K	None
130	1990-2003	4	2		625-820	62-79	160	45	Brn to Red	Blue to Blk/Red	280-460	2.5	Wht/Red to White/Yel Wht/Grn to Wht/Blk	125	0.5	3.8 K	4-6 K
150/175	1984-1989	6	2		900-1100	21-27	75	14	Brn to Red	Blue to Blk/Red	280-460	1.6	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	105	0.5	2.5 K	4-6 K
150/175	1990-1995	6	2		660-820	62-79	145	40	Brn to Red	Blue to Blk/Red	280-460	2	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	105	0.5	3.8 K	4-6 K
150	1996-2004	6	2	D/L/P/S	660-820	62-79	145	40	Brn to Red	Blue to Blk/Red	280-460	3	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	130	0.5	4.1 K	5 K
150	1996-1999	6	2	C	460-620	70-90	90	30	Brn to Red	Blue to Blk/Red	280-460	2.5	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	65	0.5	4.1 K	None
150	1999-2003	6	2	DX/SX/VX	224-336		110		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red to Blk Wht/Grn to Blk Wht/Blk to Blk Wht/Blue to Blk Wht/Yel to Blk Wht/Brn to Blk	100	0.5	2.72 - 3.68 K	None
150	1999-2002	6	2	LX/PX	224-336		110		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red to Blk Wht/Grn to Blk Wht/Blk to Blk Wht/Blue to Blk Wht/Yel to Blk Wht/Brn to Blk	100	0.5	2.72 - 3.68 K	None
150	1994-1995	6	2	P	660-820	62-79	145	40	Brn to Red	Blue to Blk/Red	280-460	2.5	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	65	0.5	3.8 K	None
150	2000-2004	6	2	Z/LZ/VZ	CDI OUTPUT		140		Blk/Org, Blk/Yel, Blk/Blue, Blk/Grn, Blk/Wht to Red/Yel		?	5	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	140			4-6 k
150	2004	6	4	F/LF	ECM OUTPUT		260		Blk/Org to Blk Blk/Wht to Blk		459-561	3.5	White/Red to Blk White/Blk to Blk	260	1.53-2.07	12.5 - 16.91 K	None

YAMAHA DVA and RESISTANCE CHARTS

HP	YEAR	# Cyl	STK	MDL	STATOR						TRIGGER			CDI Out	IGNITION COIL		SPK PLG
					OHMS		DVA		CHECK POINTS		OHMS	DVA	CHECK POINTS		OHMS +/- 10%		CAP
					L Spd	HSpd	LS	HS	HS	LS	Ohms	DVA			Primary	Sec	
175	1996-2000	6	2		660-820	62-79	140	40	Brn to Red	Blue to Blk/Red	280-460	2.5	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	130	0.5	4.1 K	5 K
175	2001-2004	6	2	Z/VZ	CDI OUTPUT		140		Blk/Org, Blk/Yel, Blk/Blue, Blk/Grn, Blk/Wht to Red/Yel		?	5	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	140			4-6 K
200	1984-1989	6	2		900-1100	21-27	75	14	Brn to Red	Blue to Blk/Red	280-460	1.6	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	105	0.5	2.5 K	
200	1990-1995	6	2		660-820	62-79	145	40	Brn to Red	Blue to Blk/Red	280-460	2.5	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	105	0.5	3.8 K	None
200	1991-1995	6	2	P	660-820	62-79	145	40	Brn to Red	Blue to Blk/Red	280-460	2	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	105	0.5	3.8 K	None
200	1996-1999	6	2	L/P/S	660-820	62-79	140	40	Brn to Red	Blue to Blk/Red	280-460	2.5	Wht/Red to Wht/Grn Wht/Blk to Wht/Blue Wht/Yel to Wht/Brn	130	0.5	4.1 K	5 K
200	1998	6	2	V	224-336		115		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100	0.5	2.7 - 3.6 K	5 K
200	2002-2004	6	4	F	CDI OUTPUT		252		Blk/Org, Blk/Yel, Blk/Wht to Red/Yel		459-561	5.3	Wht/Red to Blk Wht/Grn to Blk Wht/Blk to Blk	252	1.5-1.9	19.6 - 35.4 K	None
200	1999-2002	6	2	LX	CDI OUTPUT		140		Blk/Org, Blk/Yel, Blk/Blue, Blk/Grn, Blk/Wht to Red/Yel		?	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	140			4-6 K
200	1999-2004	6	2	SX	CDI OUTPUT		100		Blk/Org, Blk/Yel, Blk/Blue, Blk/Grn, Blk/Wht to Red/Yel		?	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100			4-6 K
200	1999-2004	6	2	V/VX	224-336		115		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100	0.5	2.7-3.6 k	5 K

YAMAHA DVA and RESISTANCE CHARTS

HP	YEAR	# Cyl	STK	MDL	STATOR						TRIGGER			CDI Out	IGNITION COIL		SPK PLG
					OHMS		DVA		CHECK POINTS		OHMS	DVA	CHECK POINTS		OHMS +/- 10%	CAP	
					L Spd	HSpd	LS	HS	HS	LS	Ohms	DVA			Primary	Sec	
200	2000-2004	6	2	LZ/Z HPDI	CDI OUTPUT		140		Blk/Org, Blk/Yel, Blk/Blue, Blk/Grn, Blk/Wht to Red/Yel		?	5	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	140	0.5		4-6 K
220	1984-1986	6	2		900-1100	21-27	75	14	Brn to Red	Blue to Blk/Red	280-460	1.6	Wht/Red to Wht/Grn, Wht/Blk to Wht/Blue, Wht/Yel to Wht/Brn	58	0.5	2.5 K	5 K
225	1984-1989	6	2		900-1100	21-27	75	14	Brn to Red	Blue to Blk/Red	280-460	1.6	Wht/Red to Wht/Grn, Wht/Blk to Wht/Blue, Wht/Yel to Wht/Brn	58	0.5	2.5 K	5 K
225	1990-1995	6	2	L/HP	660-820	62-79	145	40	Brn to Red	Blue to Blk/Red	280-460	2	Wht/Red to Wht/Grn, Wht/Blk to Wht/Blue, Wht/Yel to Wht/Brn	105	0.5	3.8 K	5 K
225	1996-1997	6	2	L/HP	660-820	62-79	145	40	Brn to Red	Blue to Blk/Red	280-460	2	Wht/Red to Wht/Grn, Wht/Blk to Wht/Blue, Wht/Yel to Wht/Brn	130	0.5	4.1 K	5 K
225	1994-1995	6	2	X/HP U/HP	224-336	224-336	90	90	Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100	0.5	2.7 K	5 K
225	2002-2004	6	4	F	CDI OUTPUT		252		Blk/Org to Red/Yel, Blk/Yel to Red/Yel, Blk/Wht to Red/Yel		459-561	5.3	Wht/Red to Blk, Wht/Grn to Blk, Wht/Blk to Blk	252	1.5-1.9	19.6-35.4 k	None
225	1996-2002	6	2	S/X/U L/LX/SX	224-336		115		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100	0.5	2.7 K	5 K
225	1998-2004	6	2	VX	224-336		115		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100	0.5	2.7 K	5 K
225	2003-2004	6	2	VZ HPDI	224-336		160		Red to Blk/Wht		294-398	3.5	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	160	1.87-2.53	8.93-12.08 K	None
250	1990-1996	6	2		224-336		90		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100	0.5	2.7 K	5 K
250	1997-2002	6	2		224-336		115		Brn to Red	Blue to Blk/Red	294-398	3	Wht/Red, Wht/Grn, Wht/Blk, Wht/Blue, Wht/Yel, Wht/Brn to Blk	100	0.5	2.7 K	5 K

YAMAHA DVA and RESISTANCE CHARTS

HP	YEAR	# Cyl	STK	MDL	STATOR						TRIGGER			CDI Out	IGNITION COIL		SPK PLG
					OHMS		DVA		CHECK POINTS		OHMS	DVA	CHECK POINTS		OHMS +/- 10%		CAP
					L Spd	HSpd	LS	HS	HS	LS	Ohms	DVA			Primary	Sec	
250	2003-2004	6	2	HPDI	CDI OUTPUT		160		Red to Blk/Wht		294-398	3.5	Wht/Red to Blk Wht/Grn to Blk Wht/Blk to Blk Wht/Blue to Blk Wht/Yel to Blk Wht/Brn to Blk	140	1.87-2.53	8.93-12.08 K	None
300	2004	6	2	LZ/VZ/Z HPDI	CDI OUTPUT		265		Red to Blk/Wht		294-398	3.5	Wht/Red to Blk Wht/Grn to Blk Wht/Blk to Blk Wht/Blue to Blk Wht/Yel to Blk Wht/Brn to Blk	265	1.36-1.84	7.31 - 9.89 K	None

Glossary of Terms

ADI – **Alternator Driven Ignition**, consists of a flywheel, stator, trigger and ignition module.

ADTC - **After Top Dead Center** Reference on ignition timing.

BTDC - **Before Top Dead Center** Reference on ignition timing.

CD Ignition – **Capacitive Discharge Ignition**. The capacitor stores the power developed by a stator or inverter and uses a SCR to deliver the power to the ignition coil.

CDM – **Capacitive Discharge Module**. The CDM is a combination of the switch box and ignition coil.

Crank - Refers to the engine being turned over with the starter, not running. Spark plug wires are usually connected to a spark gap tester.

DVA – **Direct Voltage Adapter**. Also known as Peak voltage. The term refers to the peak voltage as read by a specialized meter or a multimeter using a adapter to convert the peak voltage in the ignition system to a DC value. Regular meters cannot read the voltages due to the frequency and duration of the pulses in the system.

Power Pack – Term used by Johnson/Evinrude for the ignition module.

RPM – **Revolutions per minute**. The number of times the engine rotates in one minute.



S.L.O.W. – **Speed Limiting Oil Warning** system. Limits the RPM of the engine to approximately 2500 RPM in order to reduce the damage to the engine caused by a no oil or overheat condition.

Spark Tester - Device used to check for spark from the ignition coil to the spark plug. Testers are normally available in 1, 4, 6 and 8 cylinder configurations.


Switch Box – Term used for Force, Mariner and Mercury ignition modules.

W.O.T. – **Wide Open Throttle**.

Modified Engine Wiring Diagrams for CDI Electronics Components



Modified Engine Wiring Diagrams for CDI Electronics Components



Modified Engine Wiring Diagrams for CDI Electronics Components

